

RVE32 Series Variable Frequency Drive user's manual



Prior to use, please read this user's manual carefully.

CAUTION: Please keep this user's manual for future reference.

RVE32 series variable frequency drive

User's Manual

V 24.12

CONTENTS

| | |
|--|----|
| 1 PREFACE | 1 |
| 2 CHECKING BEFORE USE | 1 |
| 2.1 Label | 2 |
| 2.2 Model Description | 2 |
| 2.3 RVE32 Series VFD Specification | 2 |
| 2.4 Appearance & Dimensions | 4 |
| 2.4.1 Appearance & installation Size of 380V VFD | 4 |
| 3. BASIC WIRING DIAGRAM | 7 |
| 3.1 Basic Wiring Diagram | 7 |
| 3.2 Main Circuit Terminals | 9 |
| 3.2.1 Main Circuit Terminals Structure of 380V VFD | 9 |
| 3.3 Control Terminals | 11 |
| 3.3.1 Control terminals structure of 380V VFD | 11 |
| 3.3.2 Description of Control Terminals Function | 11 |
| 4 APPEARANCE OF KEYBOARD PANEL | 13 |
| 4.1 Appearance of keyboard panel | 13 |
| 4.1.1 Description and function of each part of the keyboard panel (380V VFD) | 13 |
| 5 BASIC OPERATING & RUNNING | 14 |
| 5.1 Basic Performance Table | 14 |
| 5.2 Basic operation of Panel | 16 |
| 5.2.1 Running model selection | 16 |
| 5.2.2 Powering-on default mode | 16 |
| 5.2.3 Parameter Setting Mode | 17 |
| 5.2.4 Status monitoring mode | 17 |
| 5.2.5 Parameter verifying mode | 18 |
| 5.3 Power on | 18 |
| 5.4 Running | 19 |
| 5.4.1 Local control mode | 19 |
| 5.4.2 Remote control mode | 19 |
| 6 FUNCTION PARAMETER | 24 |
| 6.1 Parameter Table | 24 |
| 6.1.1 F0 Group | 24 |
| 6.1.2 F1 Group | 26 |
| 6.1.3 F2 Group | 27 |
| 6.1.4 F3 Group | 29 |
| 6.1.5 F4 Group | 37 |
| 6.1.6 F5 Group | 40 |

| | |
|--|-----------|
| 6.1.7 F6 Group..... | 42 |
| 6.1.8 F7 Group..... | 45 |
| 6.1.9 F8 Group..... | 47 |
| 6.1.10 F9 Group..... | 49 |
| 6.1.11 U0 Group..... | 50 |
| 7 FAULT DIAGNOSIS AND MEASURES..... | 52 |
| 7.1 Fault Code, course and measures..... | 52 |
| 7.2 Description of alarm and indication code..... | 55 |
| 7.3 Restart of the VFD after fault occurs..... | 57 |
| APPENDIX A: SERIAL COMMUNICATION..... | 58 |
| A1. RS485 Bus..... | 58 |
| A2. Modbus protocol..... | 59 |
| A2.1 Description of Modbus-RTU message format..... | 59 |
| A2.2 Detailed message description of different commands..... | 60 |
| A2.3 Cyclic redundancy check (CRC) | 63 |
| A2.4 Error code..... | 64 |
| A2.5 Communication parameter..... | 64 |
| APPENDIX B: BRAKE UNIT/RESISTANCE SELECTION | 69 |

1 Preface

Thank you for using RVE32 series variable frequency drive (Hereinafter referred to as VFD).

This Use's Manual offers complete introduction of performance, installation and use of the VFD, setting of function parameters, operation etc for RVE32 VFD. Before use (installation, operation, maintenance, inspection, etc.), Please be sure to read it carefully. In addition, please understand the safety precautions of the product before using it. There is two safety identity in this manual:

Dangerous

The electronic components inside the VFD are particularly sensitive to static electricity, so do not place foreign objects inside the VFD or touch the main circuit board.

Do not touch the VFD and surrounding circuits with wet hands before and after powering on.

Note

All cover plates must be installed and closed before power supply; After power, do not open the cover plate, do not touch any input and output terminals of the VFD. Please properly ground the VFD according to the standard, otherwise there is danger of electric shock.

2 Checking Before Use




When opening the box, please carefully check and confirm:

- (1) If the product inside together with the quality certificate, user's manual and warranty card;
- (2) Please check the "Model" label on the side of the machine, and re-confirm if the product and your order are consistent;
- (3) If there's any damage, scratch or dirt (damages caused during transportation are not within the company's warranty)


If there's any damage, product missing or some other questions, please contact the dealer you purchased the product or the sales department immediately.

Note: Do not install the VFD if you find the product is damaged or component missing, otherwise it may cause safety incident.

2.1 Label

| | |
|---|-----------------------|
| Fujian Raynen Technology Co.,Ltd. | Company name |
| Model : RVE32-T3-5R5G/7R5P | VFD model |
| Max Appli Motor: 5.5kW/7.5kW | Max Motor Power |
| Input: AC3PH 380-480V 50/60Hz 20.7/26A | Input specification |
| Output: AC3PH 0-480V 0-400Hz 12.6/18.5A | Output specification |
| Operating Temperature: -10℃~40℃ | Ambient temperature |
| IP Protection: IP20 Mass: | IP level/weigght |
| S/N: | Ex-Factory Series NO. |
|    | |
| TEL: 0591-88267288 ADD: No.26,ZoneC,Software Park, No.89 Software Avenue, Gulou District, Fuzhou | Hotline /Address |

2.2 Model Description



2.3 RVE32 Series VFD Specification

Table 2.1 RVE32 three phase 380V VFD specification table


| VFD model | G type (Heavy duty load) | | | P Type (Light duty load) | | |
|--------------------|--------------------------|-------------------------|------------------|--------------------------|-------------------------|------------------|
| | Rated input current (A) | Rated output current(A) | Rated power (kW) | Rated input current (A) | Rated output current(A) | Rated power (kW) |
| RVE32-T3-0R7G/1R5P | 3.6 | 2.6 | 0.75 | 6.4 | 4.1 | 1.5 |
| RVE32-T3-1R5G/2R2P | 6.4 | 4.1 | 1.5 | 8.7 | 5.5 | 2.2 |
| RVE32-T3-2R2G/3P | 8.7 | 5.5 | 2.2 | 10.9 | 6.9 | 3 |
| RVE32-T3-3G/4P | 10.9 | 6.9 | 3 | 14 | 9.5 | 4 |
| RVE32-T3-4G/5R5P | 14 | 9.5 | 4 | 20.7 | 12.6 | 5.5 |

| VFD model | G type (Heavy duty load) | | | P Type (Light duty load) | | |
|--------------------|--------------------------|-------------------------|------------------|--------------------------|-------------------------|------------------|
| | Rated input current (A) | Rated output current(A) | Rated power (kW) | Rated input current (A) | Rated output current(A) | Rated power (kW) |
| RVE32-T3-5R5G/7R5P | 20.7 | 12.6 | 5.5 | 26.5 | 18.5 | 7.5 |
| RVE32-T3-7R5G/11P | 26.5 | 18.5 | 7.5 | 36.6 | 25 | 11 |
| RVE32-T3-11G/15P | 36.6 | 25 | 11 | 40 | 32 | 15 |
| RVE32-T3-15G/18P | 40 | 32 | 15 | 47 | 38 | 18.5 |
| RVE32-T3-18G/22P | 47 | 38 | 18.5 | 56 | 45 | 22 |
| RVE32-T3-22G/30P | 56 | 45 | 22 | 70 | 60 | 30 |
| RVE32-T3-30G/37P | 70 | 60 | 30 | 80 | 75 | 37 |
| RVE32-T3-37G/45P | 80 | 75 | 37 | 94 | 92 | 45 |
| RVE32-T3-45G/55P | 94 | 92 | 45 | 128 | 115 | 55 |
| RVE32-T3-55G/75P | 128 | 115 | 55 | 160 | 150 | 75 |
| RVE32T3-75G/90P | 160 | 150 | 75 | 190 | 180 | 90 |
| RVE32-T3-90G/110P | 190 | 180 | 90 | 225 | 215 | 110 |
| RVE32-T3-110G/132P | 225 | 215 | 110 | 265 | 260 | 132 |
| RVE32-T3-132G/160P | 265 | 260 | 132 | 310 | 305 | 160 |
| RVE32-T3-160G/185P | 310 | 305 | 160 | 355 | 350 | 185 |
| RVE32-T3-185G/200P | 355 | 350 | 185 | 385 | 380 | 200 |
| RVE32-T3-200G/220P | 385 | 380 | 200 | 430 | 425 | 220 |
| RVE32-T3-220G/250P | 430 | 425 | 220 | 485 | 480 | 250 |
| RVE32-T3-250G/280P | 485 | 480 | 250 | 545 | 530 | 280 |
| RVE32-T3-280G/315P | 545 | 530 | 280 | 610 | 600 | 315 |
| RVE32-T3-315G/355P | 610 | 600 | 315 | 665 | 650 | 355 |
| RVE32-T3-355G | 665 | 650 | 355 | - | - | - |
| RVE32-T3-400G | 785 | 725 | 400 | - | - | - |
| RVE32-T3-500G | 890 | 860 | 500 | - | - | - |
| RVE32-T3-560G | 950 | 950 | 560 | - | - | - |
| RVE32-T3-630G | 1100 | 1100 | 630 | - | - | - |
| RVE32-T3-710G | 1280 | 1280 | 710 | - | - | - |
| RVE32-T3-800G | 1380 | 1380 | 800 | - | - | - |


Notes: For 380V VFD, products of 37KW and below are standard equipped with built-in brake unit, 45KW-185KW can be equipped with built-in brake unit, 200-800kW can be equipped with external brake unit. When ordering, if you need to configure brake unit, please note in the order.

2.4 Appearance & Dimensions

2.4.1 Appearance & installation Size of 380V VFD







(c) Picture of Operating panel



(d) 380V VFD Appearance Size (three phase 15KW and below)

Table 2.4 Appearance & Installation size (three phase 380V, 15KW and below)

| Model | Outline Dimension (mm) | | | Installation Dimension (mm) | | | |
|--------------------|------------------------|------|-------|-----------------------------|------|----|----------|
| | H | W | D | H1 | W1 | W2 | Aperture |
| RVE32-T3-0R7G/1R5P | 206 | 76.5 | 168.5 | 195 | 66.5 | - | Φ5 |
| RVE32-T3-1R5G/2R2P | | | | | | | |
| RVE32-T3-2R2G/3P | | | | | | | |
| RVE32-T3-3G/4P | | | | | | | |
| RVE32-T3-4G/5R5P | 262 | 100 | 171 | 251 | 90 | - | Φ5 |
| RVE32-T3-5R5G/7R5P | | | | | | | |
| RVE32-T3-7R5G/11P | | | | | | | |
| RVE32-T3-11G/15P | 353 | 120 | 222 | 341 | 108 | 90 | Φ7 |
| RVE32-T3-15G/18P | | | | | | | |




(e) 380V VFD Appearance Size (18.5KW-315KW)

(f) 380V VFD Appearance Size(355KW-500KW)

Table 2.5 Appearance & Installation size (three phase 380V 18.5KW~315KW)

| Model (Three Phase 380V) | Outline Dimension (mm) | | | Installation Dimension (mm) | | |
|-----------------------------|------------------------|-----|-----|-----------------------------|-----|----------|
| | H | W | D | H1 | W1 | Aperture |
| RVE32-T3-18G/22P | 335 | 200 | 195 | 321 | 140 | Φ9 |
| RVE32-T3-22G/30P | | | | | | |
| RVE32-T3-30G/37P | 410 | 260 | 214 | 396 | 180 | Φ9 |
| RVE32-T3-37G/45P | | | | | | |
| RVE32-T3-45G/55P | 520 | 288 | 236 | 500 | 200 | Φ9 |
| RVE32-T3-55G/75P | 560 | 305 | 300 | 543 | 200 | Φ11 |
| RVE32-T3-75G/90P | | | | | | |
| RVE32-T3-90G/110P | 600 | 310 | 310 | 583 | 240 | Φ11 |
| RVE32-T3-110G/132P | | | | | | |
| RVE32-T3-132G/160P | 720 | 355 | 345 | 698 | 240 | Φ13 |
| RVE32-T3-160G/185P | | | | | | |
| RVE32-T3-185G/200P | | | | | | |
| RVE32-T3-200G/220P | 920 | 480 | 390 | 898 | 320 | Φ13 |
| RVE32-T3-220G/250P | | | | | | |
| RVE32-T3-250G/280P | 1100 | 480 | 405 | 1078 | 320 | Φ13 |
| RVE32-T3-280G/315P | | | | | | |
| RVE32-T3-315G/355P | | | | | | |
| RVE32-T3-355G | 1100 | 650 | 465 | 1060 | 350 | Φ17 |
| RVE32-T3-400G | | | | | | |
| RVE32-T3-500G | | | | | | |




(g) VFD Appearance Size(three phase 380V 560KW and above)

Table 2.6 Appearance & installation size (three phase 380V 560KW-800KW)


| Model (Three Phase 380V) | Outline Dimension (mm) | | | Installation Dimension (mm) | | |
|-----------------------------|------------------------|------|-----|-----------------------------|----|----------|
| | H | W | D | H1 | W1 | Aperture |
| RVE32-T3-560G | 2200 | 1100 | 800 | - | - | - |
| RVE32-T3-630G | | | | | | |
| RVE32-T3-710G | 2200 | 1400 | 800 | - | - | - |
| RVE32-T3-800G | | | | | | |

3. Basic Wiring Diagram

3.1 Basic Wiring Diagram



(a) Standard wiring diagram for 15kW (inclusive) and below




<1> 18.5-37kW inverters do not have P0 terminals; for inverters above 45kW (inclusive), be sure to remove the short-circuit between P0 and (+) when installing the DC reactor (optional).

<2> 18.5-37kW inverters have PB terminals, and a brake resistor can be connected between PB and (+).


(b) Standard wiring diagram for inverters above 18.5kW (inclusive)

3.2 Main Circuit Terminals


3.2.1 Main Circuit Terminals Structure of 380V VFD




(a) Main Circuit Terminal (380V/0.75-3kW)




(b) Main Circuit Terminal (380V/4-7.5kW)




(c) Main Circuit Terminal (380V/11-15kW)




(d) Main Circuit Terminal (380V/18.5-22kW)




(e) Main Circuit Terminal (380V/30-37kW)




(f) Main Circuit Terminal (380V/45kW)




(g) Main Circuit Terminal (380V/55-75kW)




(h) Main Circuit Terminal (380V/90-110kW)




(i) Main Circuit Terminal (380V/132-185kW)




(j) Main Circuit Terminal (380V/200-220kW)



(k) Main Circuit Terminal (380V/250-315kW)




(l) Main Circuit Terminal (355-500kW)




(m) Main Circuit Terminal (560-800kW)

Table 3.2 Function of Main Circuit Terminals of 380V VFD


| Symbol | Function |
|---|---|
| R/L1、S/L2、T/L3 | Input of VFD, Terminal for Connection three phase AC Power source, 380V,50Hz /60Hz |
| U/T1、V/T2、W/T3 | Output of VFD, Terminal for connection to three phase induction motor |
| +、- | DC bus terminal, connect to braking unit etc " +" is the positive terminal of DC bus, "-" is the negative terminal |
| PA/+、PB +、PB | Connection of braking resistor, connection to braking resistor PA/+、+ ——positive terminal of DC power input |
| P0、+ | DC Reactor terminal, connect DC reactor |
|  | Terminal for grounding, 380V : grounding resistance is 4Ω or below. |

3.3 Control Terminals

3.3.1 Control terminals structure of 380V VFD



(a) Control terminal (380V/15kW and below)




(b) Control terminal (380V/18.5kW and above)

3.3.2 Description of Control Terminals Function


| Symbol | Item | Function |
|-----------|--|--|
| 0V | | Common terminal of the control circuit |
| 5V | 5V output voltage | Commonly used as working voltage of the external potentiometer, Maximum current:10mA. Accuracy:±5% |
| 24V | 24V output voltage | Commonly used as working voltage of the logic input terminal, Maximum current:100mA accuracy:±20% |
| AI1 | Voltage/current analog input Or programmable logic input | Voltage/current analog input: accuracy:10 bit Analog voltage input:0 ~ +5 V or 0 ~ +10 V ,input Reactance 30K,Analog current input: Max 20mA,input Reactance 250Ω. By changing parameter setting, the AI1 can also be used as a programmable logic input terminal. If that, a resistor (4.7kΩ ~10k Ω, 1/2W) must be added between 24V - AI1; At the same time, set AI1 to 10V analog voltage input.see Figure 1. |
| AI2 | Voltage Analog input Or programmable logic input | Voltage analogy input: Accuracy:10 bit Maximum range: 0 ~ +10 V, input Reactance 30K, By changing parameter setting, the AI2 can also be used as a programmable logic input terminal. If that, a resistor (4.7kΩ ~10k Ω, 1/2W) must be added between 24V and AI2 ,Reference AI1. |
| L11 ~ L18 | programmable logic input | +24 V Power supply Positive Logic(source): port voltage < 5 V, input invalid (OFF), port voltage > 11V, input valid (ON); Negative Logic (sink): port voltage > 16V , input invalid (OFF); port voltage < 10V, input valid (ON); Logic input connection diagram refers to Figure 2. |

| Symbol | Item | Function |
|----------------------|---------------------------------|---|
| AO1 AO2 | Voltage/Current analog output | Analog voltage output: 0 ~ +10 V ,Min load reactance is 470Ω Analog current output: x ~ 20 mA, Max load reactance is 700Ω |
| LO | Pulse output collector | Maximum current:100mA Maximum voltage:30V |
| CLO | Pulse output emitter | |
| T1A | Relay 1-Normally open terminal | Maximum switching capacity: T1A-T1C: 5A @ 250VAC,5A @ 30VDC T1B-T1C: 3A @ 250VAC,3A @ 30VDC |
| T1B | Relay 1-Normally close terminal | |
| T1C | Relay 1-Common terminal | |
| T2A | Relay 1-Normally open terminal | Maximum switching capacity: T2A-T2C: 5A @ 250VAC,5A @ 30VDC T2B-T2C: 3A @ 250VAC,3A @ 30VDC |
| T2B | Relay 1-Normally close terminal | |
| T2C | Relay 1-Common terminal | |
| 485+ /485- A+ /B- | RS485 communication port | The forth feet (A+) is positive port of RS485 differential signal, the fifth feet (B-) is the negative port of RS485 difference signal. |
| SW700 | RS485 Reactance marching | SW700 is only for 18.5KW and above VFD. SW700 total has 3 switch, from left to right is as below: SW700-1:ON-connect 'RS485+' signal's pull-up resistance; SW700-2:ON-connect 'RS485-' signal's pull down resistance; SW700-3:ON-connect 'RS485+,- ' signal between matched resistance; |



For 380V VFD: 4.7~10KΩ


(a) Positive Logic – source




For 380V VFD : 4.7~10KΩ

(b) negative logic– sink

Figure1: AI1 Wiring diagram when AI1is logic input terminal



(a) positive logic – source




(b) negative logic– sink

Figure 2: Logic input terminal wiring diagram

4 Appearance of keyboard panel

4.1 Appearance of keyboard panel



4.1.1 Description and function of each part of the keyboard panel (380V VFD)

| NO. | Designation | Sign | Functional performance |
|-----|--------------------------------|------|--|
| 1 | Display area 1 | — | LED digital display for showing function parameters and set values, etc. |
| 2 | Display area 2 | — | LED digital display for monitoring values. |
| 3 | Running status indicator | RUN | On: The operation command and frequency setting are valid, and the output of the VFD is normal; Flash: The running command is valid, but the frequency setting is invalid. The VFD has no output; Off: Currently no running command, no output of the VFD, in standby state. |
| 4 | Reverse status indicator light | REV | On: Reverse Off: Forward |
| 5 | Local status indicator | LOC | On: Local Off: Remote |
| 6 | Failure status indicator | ALM | On: Failure Off: No failure |
| 7 | Unit light | % | The current display data is a percentage. |
| | | Hz | The unit of data currently displayed is Hz. |
| 8 | Mode | MODE | Select the operating mode of the VFD or go back to mode from the sub-menu. |
| 9 | Escape) | ESC | Exits the current state and returns to the previous state. |
| 10 | Jog reset | JOG | Default is shortcut menu 3. See parameter f700 for Settings. |
| 11 | Run | RUN | Turn on VFD output. |

| NO. | Designation | Sign | Functional performance |
|-----|--------------------|----------------|---|
| 12 | Enter | ENTER | Enter mode, view parameters, or confirm set values. |
| 13 | Up | ▲ | Add parameter number and parameter setting value. |
| 14 | Down | ▼ | Reduce parameter number and parameter setting value. |
| 15 | Stop/reset | STOP/ RESET | Stop the output of the converter and change to the reset button when fault is detected. |
| 16 | Speed control knob | — | Adjust the speed. |

5 Basic Operating & Running

5.1 Basic Performance Table

| Item | | Instruction |
|-------------------------------|---|--|
| Power Input | Rated voltage | T3 (Three phase 380V) : three phase AC voltage, 380~480V |
| | Rated Frequency | 50/60Hz ± 5% |
| Output Power | Input Power | 0-100% input voltage |
| | Rated input current | According to each model, see standard spec.2.3 |
| | Overload | 150% Rated output current.60s, 200% Rated output current 2s |
| Control Function | Control Mode | V/f control for constant torque, V/f control for quadratic load, vector control without PG (open loop control),Energy-saving |
| | Setting method of Frequency command | External terminal (including Logic multi-speed, analog input, UP/DOWN given), keyboard, serial communication |
| | Setting method of run command | External terminal, keyboard panel or serial communication |
| | Frequency set precision | Keyboard、UP/DOWN given: 0.1Hz |
| | | Analog given, serial communication: 10bit (0.05Hz/50Hz) |
| | Low frequency torque | No PG V/f Control: 150%Rated torque/3Hz |
| | | No PG Vector control: 150% rated torque/0.5Hz |
| | Speed control range | No PGV/f control: 1: 40 |
| | | No PG Vector control: 1: 200 |
| | Speed control precision | No PGV/f control: ±2% |
| No PG Vector control: ±0.2% | | |
| Acc / Dec time | 0-3200.0s | |
| switching frequency | 1.5kHz ~ 12kHz,according to junction temperature automatically reduce the switching frequency | |
| Built-in control power supply | Output Voltage | 5VDC±5% (1ways) , 24VDC±5% (1ways) |
| | Max load | 5V: Max current 10mA, For reference potentiometer 24V: Max current 100mA, for logic input |

| Item | | Instruction |
|-------------------------|---------------------|---|
| Analog input | Number | 2 ways: AI1、 AI2 |
| | Type | DC voltage or DC current |
| | Maximum input range | AI1: 0-5VDC, or 0-10VDC, or 0/4-20mADC AI2: 0-10VDC, or PTC probe input receivable |
| Analog output | Number | 2ways, ,AO1, A02 |
| | Type | DC voltage or DC current |
| | Maximum input range | 0-10VDC, or 0/4-20mADC |
| | Function selection | Output frequency, output current, speed given, Serial output data, etc. |
| Logic input | Number | 0.75-15KW 8 ways: LI1 to LI6、 AI1、 AI2 18.5-800KW 10 ways: LI1 to LI8、 AI1、 AI2 notes: AI1、 AI2 can be used as logic input port (positive logic or negative logic) |
| | Type | Positive Logistic (Source) Or Negative Logistic (Sink) |
| | Input voltage | 0-24VDC |
| | Function Selection | FWD,REV, running, fault reset,multi-speed,etc. |
| Logic output | number | 2ways pulse signal output (LO-CLO) 、 relay output 1way or 2 ways. |
| | pulse signal output | OC, output frequency、 current output、 and other function |
| | relay output | T1A is normally open,T1B is normally closed, T1C is common terminal T2A is normally open,T2B is normally closed, T2C is common terminal Probe capacity: T1A-T1C / T2A-T2C: 5A@250VAC, 5A@30VDC T1B-T1C / T2B-T2C: 3A@250VAC, 3A@30VDC Function choose: Fault, alarm, set frequency reach,etc. |
| communication interface | Hardware protocol | RS-485 |
| | Software protocol | Modbus |
| Structure | Protection Level | IP20 |
| | Cool method | Forced Air cooling |
| Environment | Installation site | Indoor |
| | Work temperature | -10 ~ 50°C |
| | Storage temperature | -20 ~ 60°C |
| | Humidity | Below 95RH% (No moisture condensation) |
| | Altitude | 1000m normal using, 1000-3000m, every 100m higher the power KW will reduce 1% |

5.2 Basic operation of Panel

5.2.1 Running model selection

The VFD include four running models: Powering-on default mode、 Parameter setting mode、 Status monitoring mode and Parameter verifying mode. Any mode can be realized by the MODE Key, showed as Figure5.1




Figure 5.1 Structure of VFD Mode switch

Notes : when f618=1, showed parameter setting mode

5.2.2 Powering-on default mode

The display data is the current output frequency under Powering-on default mode, so directly use ▲ or ▼ key to modify the digital frequency setting, then press the ENT key to save the modified data and return Powering-on default mode, As showed as Figure5.2




Figure 5.2 Powering-on default mode Navigation

Notes : Here the display data type can be set freely under the Powering-on default mode, showed in the parameter f610

5.2.3 Parameter Setting Mode

There are 10 groups function parameters from F0 group to F9 group, each group includes different numbers function parameter. The parameter setting value can be modified by ▲ or ▼ key and ENT key, or give up the modification by ESC key, as showed as Figure5.3




Figure 5.3 Parameter Setting Mode navigation

5.2.4 Status monitoring mode

The status monitoring mode can be used to monitor the current running status of VFD , or check the fault record, the operation shows as the Figure 5.4




Figure 5.4. State monitoring mode navigation

Notes: Monitoring parameter only can be used to check, cannot be modified or set.

5.2.5 Parameter verifying mode

When f618=1, use MODE key to switch to parameter calibration mode. Under this mode, we can see all different parameters from the default value. The setup method for these parameters is the same to other parameter setup way. Please see figure 5.5.

Remarks: No other display only “-uf-” when pressing the ENT key without change to any parameter




Figure 5.5 Parameter verifying mode navigation

5.2.6 Jog

In power-on mode, when F70G=1, press the JOG key to enter the jog state directly. After entering the jog state, the display data changes to JOG or -JOG, indicating forward jog and reverse jog respectively. In local mode, the jog direction can be switched by pressing or ▼ on the operation panel. For details on the setting of jog frequency and jog stop mode, please refer to the introduction of F701 and F702.

5.3 Power on

Before switching on the VFD, please do check and confirm according to table 5.1, or there may be dangerous.

Table 5.1 Inspection Item before Power on

| Item | Instruction |
|-------------------------------|---|
| Input power voltage | Please confirm if the power supply is correctly connected (3-phase, AC380V~ 480V, 50/60 Hz) Please confirm if the power supply input terminals R/L1, S/L2, T/L3 are properly connected. Please confirm whether the VFD and the motor are correctly grounded. |
| Main circuit output terminals | Please confirm the output terminals of the VFD (U, V ,W) are reliably connected with the 3-phase input terminals of the motor. |
| Control circuit terminals | Please confirm the control circuit terminals are reliably connected with other device. All control circuit terminals are in the state OFF (The VFD does not run when powered on). |
| State of load | Please confirm the condition of the motor load (namely the status of connection with mechanical system). |

After the VFD is switched on, the keyboard panel enters into Powering-on mode. The displayed value type at Powering-on mode is determined by the setting value of parameter f610.

5.4 Running

5.4.1 Local control mode

VFD provide two control modes: local and remote. The mode is set with parameter f601.

At local control mode, both the command source and frequency setting source of the VFD are set through the keyboard panel:

(1)Command source is given through RUN and STOP keys in order to run or stop the motor.

(2)Frequency is given by ▲ and ▼ keys.

(3)Motor rotation direction: ENTER+▲——Setting motor rotation as Forward;

ENTER+▼——Setting motor rotation as Reverse (confirm the setting of f522) ;

Parameter f522 is used to limit the ability of the motor to rotate only in a single direction.

(4)Fault reset: When fault occurred, press STOP key, if show as A-00, Press STOP key again, finish fault reset function, Please see parameter f600.

5.4.2 Remote control mode

Under remote control mode, the command source and frequency setting source of the VFD are set through parameters f002 and f003 respectively. The command source and frequency setting source can be combined in any way. As show as Parameter f002、f003.

Below is the main two ways of remote control mode wiring and setting:

- (1) Remote mode example 1: 2-wire control;
- (2) Remote mode example 2: 3-wire control (negative logic);
- (3) Remote mode example 3: UP/DOWN acceleration/deceleration (negative logic);
- (4) Remote mode example 4: Multi-speed control (negative logic);
- (5) Remote mode example 5: Inching control (negative logic);

(1) Remote mode example 1: 2-wire control




Figure 5.6 Example of 2-wire control wiring diagram

Table 5.2 2 - wire control parameter configuration (negative logic)

| Code | Parameter | Settings (Deceleration stop) | Settings (Free stop) |
|------|--|------------------------------|----------------------|
| f002 | Selection of run command | 0 | 0 |
| f003 | Selection of frequency command selection | 1 | 1 |
| f300 | AI1 input function (analog or logic selection) | 0 | 0 |
| f301 | LI1 logic input function | 2 | 2 |
| f302 | LI2 logic input function | 3 | 3 |
| f304 | LI4 logic input function | 10 | 10 |
| f305 | Analog input mode setting | 0 | 0 |
| f306 | Logic Input Type Selection * | 1 | 1 |
| f309 | Forced valid logic input function | 1 | 1 |
| f310 | Forced valid logic input function 2 | 0 | 0 |
| f522 | Motor reverse prohibition | 0 | 0 |
| f523 | Motor stop type | 0 | 2 |

(2) Remote mode example 2: 3-wire control (negative logic)




Figure 5.7 Example of 3-wire control (negative logic) wiring diagram

Table 5.3 3 - wire control parameter configuration (negative logic)

| Code | Parameter | Settings (Deceleration stop) | Settings (Free stop) |
|------|--|------------------------------|----------------------|
| f002 | Run command selection | 0 | 0 |
| f003 | Frequency command selection | 1 | 1 |
| f300 | AI1 input function (analog or logic selection) | 0 | 0 |
| f301 | LI1 logic input function | 2 | 2 |

| Code | Parameter | Settings (Deceleration stop) | Settings (Free stop) |
|------|------------------------------|---------------------------------|-------------------------|
| f302 | L12 logic input function | 3 | 3 |
| f303 | L13 logic input function | 30 | 30 |
| f305 | Analog input mode setting | 0 | 0 |
| f306 | Logic Input Type Selection * | 1 | 1 |
| f309 | Force valid logic input | 1 | 1 |
| f310 | Force valid logic input 2 | 0 | 0 |
| f522 | Motor reverse prohibition | 0 | 0 |
| f523 | Motor stop type | 0 | 3 |

(3) Remote mode example 3: UP/DOWN acceleration/deceleration (negative logic)




Figure 5.8 Example of UP/DOWN acceleration/deceleration wiring diagram

Table 5.4 UP/DOWN acceleration/deceleration parameter configuration

| Code | Parameter | Setting |
|------|--|---------|
| f002 | Selection of run command | 0 |
| f003 | Selection of frequency command selection | 5 |
| f301 | L11 logic input function | 2 |
| f302 | L12 logic input function | 3 |
| f303 | L13 logic input function | 23 |
| f304 | L14 logic input function | 24 |
| f306 | Logic Input Type Selection * | 1 |
| f309 | Force valid logic input | 1 |

| Code | Parameter | Setting |
|------|---------------------------|---------|
| f310 | Force valid logic input 2 | 0 |
| f522 | Motor reverse prohibition | 0 |

(4) Remote mode example 4: Multi-speed control (negative logic)




Figure 5.9 Example of Multi-speed control wiring diagram

Table 5.5 Multi-speed control parameter configuration (negative logic)

| Code | Parameter | Setting |
|------|--|-----------------------------|
| f002 | Selection of run command | 0 |
| f003 | Selection of frequency command selection | 5 |
| f301 | LI1 logic input function | 2 |
| f302 | LI2 logic input function | 3 |
| f303 | LI3 logic input function | 6 |
| f304 | LI4 logic input function | 7 |
| f306 | Logic Input Type Selection | 1 |
| f309 | Force valid logic input | 1 |
| f310 | Force valid logic input 2 | 0 |
| f522 | Motor reverse prohibition | 0 |
| f000 | Frequency digital setting of inverter | Equivalent to multi-speed 0 |
| f716 | Multi-speed 1 | Multi-speed 1 |
| f717 | Multi-speed 2 | Multi-speed 2 |
| f718 | Multi-speed 3 | Multi-speed 3 |

Note: How to set f000: After the inverter is powered on, it displays 0.0. Press ▲ or ▼ to edit the number f000 and press ENT to save.

(5) Remote mode example 5: Jog control (negative logic)




Figure 5.10 Example of wiring for JOG control

Table 5.6 Parameter configuration of JOG control (Negative logic)

| Code | Parameter | Set Value |
|------|------------------------------|-----------|
| f002 | Selection of run command | 0 |
| f301 | LI1 logic input function | 2 |
| f302 | LI2 logic input function | 3 |
| f303 | LI3 logic input function | 4 |
| f306 | Logic Input Type Selection * | 1 |
| f309 | Force valid logic input | 1 |
| f310 | Force valid logic input 2 | 0 |
| f522 | Motor reverse prohibition | 0 |
| f701 | Jog frequency | Customize |
| f702 | Inching stop mode | Customize |

6 Function Parameter

6.1 Parameter Table

6.1.1 F0 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|------------------------------------|--|---------|-----|--------------|
| f000 | Frequency given by keypad | f009~f008 | 0.0 | ○ | |
| f001 | Motor control mode | 0: V/F constant 1: Variable torque 2: Sensor-less vector control 3: Energy saving | 0 | ● | |
| f002 | Command mode selection | 0: Terminal board 1: Keypad 2: Serial communication | 1 | ● | |
| f003 | Frequency setting mode selection | 0: Built-in potentiometer 1: AI1 input 2: AI2 input 3: Keypad(Given frequency) 4: Serial communication (Given frequency) 5: UP/DOWN setting 6: AI1+AI2 7: PID setting of keypad (PID given) 8: Simple PLC | 3 | ● | |
| f004 | Command mode selection 2 | 0: Terminal board 1: Keypad 2: Serial communication | 0 | ○ | |
| f005 | Frequency setting mode selection 2 | 0: Built-in potentiometer 1: AI1 input 2: AI2 input 3: Keypad(Given frequency) 4: Serial communication (Given frequency) 5: Set by UP/DOWN key 6: AI1+AI2 7: PID setting of keypad (PID given) 8: Simple PLC | 2 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|-----------------|-----|--------------|
| f006 | Frequency /PID given source conversion | 0: Switch between f003 and f005 1: Switch is disabled 2: Switch between f003 and f021 selected frequency/PID source 3: Switch between f005 and f021 selected frequency /PID source | 0 | ○ | |
| f007 | Maximum output frequency | 30.0~400.0 Hz | 50.0 | ● | |
| f008 | Upper limit frequency | 0.5 Hz ~f007 | 50.0 | ○ | |
| f009 | Lower limit frequency | 0.0 Hz ~f008 | 0.0 | ○ | |
| f010 | Acceleration time 1 | 0.1~3200 s | varies by model | ○ | |
| f011 | Deceleration time 1 | 0.1~3200 s | varies by model | ○ | |
| f012 | PWM carrier frequency | 1.5k~12.0 kHz | varies by model | ○ | |
| f013 | Carrier frequency control mode selection | 0: not reduced automatically 1: reduced automatically | 1 | ● | |
| f014 | Random PWM mode | 0: Disable. 1: Enable. | 0 | ○ | |
| f015 | Automatic acceleration/deceleration | 0: Disabled (manual). 1: Automatic (at acceleration & deceleration) 2: Automatic (only at acceleration) | 0 | ● | |
| f016 | Factory reserved | - | - | | |
| f017 | Terminal control macro | 0: Factory Settings 1: 2-wire control (Negative logic mode, ramp stop). 2: 3-wire control (Negative logic mode, ramp stop). 3: External input UP/DOWN setting (Negative logic mode, slowdown stop). 4 ~ 16: Factory reserved 17: PID sleep & Wake Control 18: PID basic control 19: Factory reserved 20: JY common macro parameter | 0 | ● | |
| f018 | Factory reserved | - | - | | |
| f020 | Factory reserved | - | - | | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---|---------|-----|--------------|
| f021 | Operational relationship between primary frequency and secondary frequency | 0: Single channel given 1: f003 + f005 2: f003-f005 3: MAX (f003, f005) 4: MIN (f003, f005) | 0 | ○ | |
| f022 | f005 frequency given coefficient | 0.0~ 100.0% | 100.0 % | ○ | |
| f023 | f005 frequency given offset | 0.0Hz~400.0Hz | 0.0Hz | ○ | |
| f024 | Lower limit frequency selection and f005= 3/7 setting | 0~ 5 | 0 | ● | |
| F099 | F099 | Manufacturer reserve (same as f020) | | | |

6.1.2 F1 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|-------------------|--|---|-----------------|-----|--------------|
| f100 | Auto-tuning | 0: Auto-tuning disabled 1: f203 restore factory values 2: Auto-tuning enabled | 0 | ● | |
| f101 | Motor rated frequency | 25.0~400.0 Hz | 50.0 | ● | |
| f102 | Motor rated frequency voltage | 50~660 V | varies by model | ● | |
| f103 | Motor rated current | 0.1~2000.0 A | varies by model | ● | |
| f104 | Motor rated speed | 1000~30000rpm | varies by model | ● | |
| f105 | Motor no-load current | 10.0~100.0% | varies by model | ● | |
| f106 | Motor thermal protection current setting | varies by model | varies by model | ○ | |
| f107 | Motor current limit | varies by model | varies by model | ● | |
| f108 | Motor 2 rated frequency | 25.0~400.0 Hz | 50.0 | ● | |
| f109 | Motor2 rated frequency voltage | 50~660V | varies by model | ● | |
| f110 | Motor 2 thermal protection current setting | varies by model | varies by model | ○ | |
| f111 | Motor 2 current limit | varies by model | varies by model | ○ | |
| f112 ~ f115 | Factory reserved | - | | | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|-----------------------|--|---------|-----|--------------|
| f119 | Keyboard control mode | 0: Local panel 1: Remote panel | 0 | ● | |
| f120 | Default setting | 0: - 1: Restore factory settings 4: Clear fault record 5: Clear the running time of VFD 6: Clear the running time of fans 7: Clear Type fault(e-36) 8: Set the VFD to P-type mode 9: Set the VFD to G-type mode | 0 | ● | |

6.1.3 F2 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|--|-----------------|-----|--------------|
| f201 | Automatic voltage regulation (AVR function) | 0: AVR disabled-Output voltage limited enable 1: AVR enabled-Output voltage limited enable 2: AVR disabled-Output voltage limited disable 3: AVR enabled-Output voltage limited disable | 3 | ● | |
| f202 | Motor voltage boost | 0.0~30.0% | varies by model | ○ | |
| f203 | Torque boost | 0.0~30.0% | varies by model | ○ | |
| f204 | Slip frequency gain | 0~150% | 50 | ○ | |
| f205 | Exciting current coefficient | 100~130 | 100 | ● | |
| f206 | Motor 2 voltage boost | 0~30% | varies by model | ○ | |
| f207 | Speed control response coefficient | 1~150 | 40 | ● | |
| f208 | Speed frequency coefficient | 1~100 | 20 | ● | |
| f209 | Weak magnetic stall current level | 10~250 | 100 | ● | |
| f210 | Weak magnetic frequency level | 50~150 | 100 | ● | |
| f211 | Maximum output voltage adjustment coefficient | 90~120% | 104 | ● | |
| f212 | Waveform switching adjustment coefficient | 0.1~14kHz | 14.0 | ● | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|-------------------|--------------------------------|---|---------|-----|--------------|
| f213 ~ f216 | factory reserved | | | | |
| f217 | Multi-point profile V/F patter | 0: disable multi-point V/F control mode. 1: factory reserved. 2: Enable multi-point V/F control mode. | 0 | • | |
| f218 | point 1 output frequency (f1) | 0~f220 | 10.0 | • | |
| f219 | point 1 output voltage (v1) | 0~100% | 20.0 | • | |
| f220 | point 2 output frequency (f2) | f218~f220 | 20.0 | • | |
| f221 | point 2 output voltage (v2) | 0~100% | 40.0 | • | |
| f222 | point 3 output frequency (f3) | f220~f101 | 30.0 | • | |
| f223 | point 3 output voltage (v3) | 0~100% | 60.0 | • | |
| f225 | Speed Factor | 1~999 | 420 | ○ | |

6.1.4 F3 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---------------------------------|---|---------|-----|--------------|
| f300 | AI1 terminal function selection | 0: AI1 - analog input 1: AI1 - contact input (Sink mode) 2: AI1 - contact input (Source mode) | 0 | • | |
| f301 | Input logic function for LI1 | 0: No function is assigned 1: Operation license 2: Forward run command 3: Reverse run command 4: Jog run mode 5: Acceleration/deceleration 2 curve selection | 2 | • | |
| f302 | Input logic function for LI2 | 6: Preset-speed command 1 7: Preset-speed command 2 8: Preset-speed command 3 9: Preset-speed command 4 10: Fault reset 11: External fault 13: DC braking command | 3 | • | |
| f303 | Input logic function for LI3 | 14: PID control disable 15: Permission of parameter editing 16: Operation license and fault reset 17: Frequency source switch to AI1 18: Forward jog run 19: Reverse jog run 20: Frequency setting source switching | 0 | • | |
| f304 | Input logic function for LI4 | 21: Switching parameter of motor V/Hz 22: Switching motor +Current limiting+Acc/Dcc curve 23: Frequency UP signal input from external contacts 24: Frequency DOWN signal input from external contacts 25: Frequency UP/DOWN cancellation signal input from external contacts 26: External fault signal inversion 27: External overheat fault input 28: External overheat fault signal inversion 29: Forced switching from remote to local control 30: Operation holding (stop of 3-wire operation) 31: Forced switching of command mode to terminal board command | 10 | • | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|------------------------------|--|---------|-----|--------------|
| f304 | Input logic function for LI4 | 32: Display cancellation of the cumulative power amount (kWh) 33: Fire-mode control, see f419 34: Coast stop (gate off) 35: Inversion of Reset 36: Current limit level selection 37: PID control integral value clear 38: inversion of PID error signal 39: Forward running + Acc & Dec curve 2 40: Reverse running + Acc&Dec curve 2 41: Forward running+ Multi-speed section 1 | 10 | • | |
| f304 | Input logic function for LI2 | 42: Reverse running + Multi-speed section 1 43: Forward running+ Multi-speed section 2 44: Reverse running+ Multi-speed section 2 45: Forward running+ Multi-speed section 3 46: Reverse running+ Multi-speed section 3 47: Forward running+ Multi-speed section 4 48: Reverse running+ Multi-speed section 4 49: Multi-speed section 1+Acc&Dec curve 2 50: Multi-speed section 2+ Acc&Dec curve 2 51: Multi-speed section 3+ Acc&Dec curve 2 52: Multi-speed section 4+ Acc&Dec curve 2 | 10 | • | |
| f304 | Input logic function for LI3 | 53: Forward running command+Multi-speed section 1+ Acc&Dec curve 2 54: Reverse running command+Multi-speed section 1+ Acc&Dec curve 2 55: Forward running command+Multi-speed section 2+ Acc&Dec curve 2 56: Reverse running command+Multi-speed section 2+ Acc&Dec curve 2 57: Forward running Acc&Dec curve 2 command +Multi-speed section 3+Acc&Dec curve 2 | 10 | • | |
| f304 | Input logic function for LI4 | 58: Reverse running command+Multi-speed section 3+ Acc&Dec curve 2 59: Forward running comman+Multi-speed section 4+ Acc&Dec curve 2 60: Reverse running command+Multi-speed section 4+ Acc&Dec curve 2 61: UP/DOWN speed clean up+ fault reset 62: Running permission+ Forward running command (only 2-wire control) | 10 | • | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--------------------------------------|--|---------|-----|--------------|
| f304 | Input logic function for LI1 | 63: Running permission+ reverse running command (only 2-wire control) 64: Acc&dec curve 3 65: Acce/Dece curve 3+ Forward running command | 10 | • | |
| f304 | Input logic function for LI2 | 66: Acce/Dece curve 3+ Reverse running command 67: Command source switch 68: Command source+ frequency source switch | 10 | • | |
| f304 | Input logic function for LI3 | 69: Three-wire control stop input reverse 70: Simple reset when PLC stops 71: Simple PLC hold 72: Simple PLC pause 73: PID disable (14) + Frequency given source switching | 10 | • | |
| f304 | Input logic function for LI4 | 74: 73 function reverse 75: (UP/DOWN) stop speed clearance 76:2-wire control mode2-start/stop control 77:2-wire control mode2-FWD/REV control | 10 | • | |
| f305 | AI1 voltage-current input selection | 0: 0 ~ 5V voltage signal input. 1: 0 ~ 10V voltage signal input. 2: current signal input. | 0 | • | |
| f306 | sink/soruce mode selection | 0: Source (Positive) logic terminal mode. 1: Sink (Negative) logic terminal mode | 1 | • | |
| f307 | AO voltage-current output selection | 0: Current signal output. 1: Voltage signal output. | 1 | • | |
| f308 | Input terminal function of AI1 | 0-75, see f301~f304 | 0 | • | |
| f309 | Always-active terminal selection 1 | 0-75, see f301~f304 | 1 | • | |
| f310 | Always-active terminal selection 2 | 0-75, see f301~f304 | 0 | • | |
| f311 | Output terminal function A of LO-CLO | f315 | 4 | • | |
| f312 | Output terminal function B of LO-CLO | f315 | 255 | • | |
| f313 | AI2 terminal function selection | 0: AI2 - analog input 1: AI2 - contact input (Sink) 2: AI2 - contact input (Source) | 0 | • | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---------------------------------------|--|---------|-----|--------------|
| f314 | Input terminal function of AI2 | 0-75, f301~f304 | 0 | • | |
| f315 | Main function of relay1 (T1A-T1B-T1C) | 0: Output frequency higher than lower limit frequency 2: Output frequency equals to upper limit frequency 4: Output frequency is higher or equal to f337 6: (set frequency -f339) < output frequency < (set frequency +f339) 8: (f338-f339) < output frequency < (f338+f339) 10: Output frequency higher or equal to f338+f339 12: f003 or f005 source supply given speed=AI1 signal 14: f003 or f005 source supply given speed=AI2 signal 16: AI1's value higher or equal to f340+f341 18: AI2's value is higher or equal to f342 +f343 20: AI2 is the speed given source 22: VFD forward motor power supply (acceleration, deceleration, constant speed or DC braking) 24: Ready for running of the VFD (running permission and running command available) 26: Motor reverse running 28: Under local mode for VFD 30: No fault output during automatic fault reset attempt 32: Evaluated motor torque is at f412 level time is still less than f414 set value. 34: Motor current is less than f408 and its lasting time is over f410 setting. 36: Fault occurred and could not reset. 38: Fault occurred but it could reset. 40: Fault input during automatic fault reset attempt 44: Motor heating status has reached 50% of motor overload fault level. | 40 | • | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|--|---------|-----|--------------|
| f315 | Output terminal function A of T1 (T1A-T1B-T1C) | 46: Braking resistor status has reached 50% braking resistor overload fault level. 48: Evaluated motor torque reaches $f412 \times 70\%$ 52: The equipment sends maintenance alarmwarning. (Fan, PCB or capacitor needs replacement.) 56: Undervoltage alarm is valid. 58: Brake pull 60: In the process of motor acceleration process 62: In the process of motor deceleration 64: In the process of motor deceleration or acceleration 66: Heat sink temperature has reached alarm value 68: One PLC recycle completes 70: One PLC speed section completes 72: The inverter is ready to receive the running signal 74: Communication address 0xfa15 bit0 state output 76~79: Factory reserve 80: LI1 input is valid 82: LI2 input is valid 84: PID feedback pressure equal to or higher than $f627 + f628$ 86: PID feedback pressure equal to or higher than $f918 + f628$ 88: communication address 0xFA15 bit1 state output 90~253: Unused 254: Relay constant output OFF 255: Relay constant output ON | 40 | • | |
| f316 | Output terminal logic selection of LO-CLO | 0: And logic 1: Or logic | 0 | • | |
| f317 | LO1-CLO1 output delay | 0.0~60.0 s | 0.0 | ○ | |
| f318 | Relay 1 closing delay | 0.0~60.0 s | 0.0 | ○ | |
| f319 | External contact input --UP-speed response time | 0.0~10.0 s | 0.1 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|-----------------------------------|--------------------|-----|--------------|
| f320 | External contact input --UP-speed frequency steps | 0.0 Hz ~f007 | 0.1 | ○ | |
| f321 | External contact input - DOWN response time | 0.0~10.0 s | 0.1 | ○ | |
| f322 | External contact input - DOWN frequency steps | 0.0 Hz ~f007 | 0.1 | ○ | |
| f323 | Initial up/down frequency | 0.0 Hz ~f007 | 0.0 | ○ | |
| f324 | Reset of the initial up/down frequency | 0/2/4: disabled 1/3/5: enabled | 1 | ○ | |
| f325 | AI1speed setting level 1 | 0~100% | 0 | ○ | |
| f326 | AI1 output frequency level 1 | 0.0~400.0 Hz | 0.0 | ○ | |
| f327 | AI1speed setting level 2 | 0~100% | 100 | ○ | |
| f328 | AI1 output frequency level 2 | 0.0~400.0 Hz | 50.0 | ○ | |
| f329 | AI2 speed setting level 1 | 0~100% | 0 | ○ | |
| f330 | AI2 output frequency level 1 | 0.0~400.0 Hz | 0.0 | ○ | |
| f331 | AI2 speed setting level 2 | 0~100% | 50 | ○ | |
| f332 | AI2 output frequency level 2 | 0.0~400.0 Hz | 50.0 | ○ | |
| f333 | AI1 Analog input bias | 0~255 | varies by by | ○ | |
| f334 | AI1 Analog input gain | 0~255 | varies by model | ○ | |
| f335 | AI2 Analog input bias | 0~255 | varies by model | ○ | |
| f336 | AI2 Analog input gain | 0~255 | varies by model | ○ | |
| f337 | Relay output-Low-speed output frequency signal | 0.0 Hz ~ f007 | 0.0 | ○ | |
| f338 | Relay output- output frequency signal 2 | 0.0 Hz ~f007 | 0.0 | ○ | |
| f339 | Relay output- output frequency signal 2 bandwidth | 0.0 Hz ~ f007 | 2.5 | ○ | |
| f340 | AI1 input reach detection level | 0~100% | 0 | ○ | |
| f341 | AI1 input reach detection bandwidth | 0~20% | 3 | ○ | |
| f342 | AI2 input reach detection level | 0~100% | 0 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|--|---------|-----|--------------|
| f343 | AI2 input reach detection bandwidth | 0~20% | 3 | ○ | |
| f344 | Frequency command detection bandwidth | 0.0 Hz ~f007 | 2.5 | ○ | |
| f345 | Logic output/pulse train output selection (LO- CLO) | 0: Logic output 1: Pulse train output | 0 | ● | |
| f346 | Pulse train output function selection (LO - CLO) | 0: Output frequency 1: Output current 2: Reference frequency 3: Motor frequency 4: DC bus voltage 5: Output voltage 6: Input power 7: Output power 8: AI1 Input value 9: AI2 Input value 10: Torque 11: Torque current 12: Motor overload state 13: VFD overload state 14:Braking reactor overload state | 0 | ○ | |
| f347 | Maximum numbers of pulse train | 500~1600 | 800 | ○ | |
| f348 | Analog output function selection(AO1) | 0: Output frequency 1: Output current 2: Reference frequency 3: Motor frequency 4: DC bus voltage 5: Output motor voltage 6: Input power 7: Output power 8: AI1 input value 9: AI2 input value 10: Estimated motor torque 11: Motor torque current 12: Motor overheating state 13: VFD overheating state 14: Braking reactor overload state 15: Serial communication data 16: 185% proofread 17: 150% proofread 18: 100% proofread | 0 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|-----------------|-----|--------------|
| f349 | Analog output voltage scaling(AO1) | 1~1280 | varies by model | ○ | |
| f350 | Inclination characteristic of analog output(AO1) | 0: Negative 1: Positive | 1 | ○ | |
| f351 | Bias of analog output (AO1) | 0~100% | 0 | ○ | |
| f352 | Min output frequency when AO1 = 0V | 0 Hz ~f007 | 0.0 | ○ | |
| f353 | Max output frequency when AO1 = 10V | 0 Hz ~f007 | 0.0 | ○ | |
| f354 | Analog output voltage offset calibration (AO1) | 0~255 | varies by model | ○ | |
| f355 | Ipput terminal function for L15 | f301~f304 | 0 | ● | |
| f356 | Input terminal function for LI6 | f301~f304 | 0 | ● | |
| f357 | Ipput terminal function for L17 | f301~f304 | | ● | |
| f358 | Input terminal function for LI8 | f301~f304 | | ● | |
| f359 | Main function of relay 2 | f315 | | ● | |
| f360 | Auxiliary function of relay 2 | f315 | | ● | |
| f361 | Logical relationship of relay 2 functions | 0: 'And' logic 1: 'Or'logic | | ● | |
| f362 | Closing delay of relay 2 | 0.0~60.0S | | ● | |
| f363 | Logic input terminal active mode | 8 bits - hexadecimal display, each option: 1.Valid when closed 2.Valid when disconnected | | ○ | |
| f364 | Logical input terminal filtering | 0~200 | 0 | ● | |
| f365 | Relay output 1 assistant function | f315 | 255 | ● | |
| f366 | Relay function logic relation | 0: 'And' logic 1: 'Or'logic | 0 | ● | |
| f367 | Terminal run detection selection at power on | 0: disable 1: enable | 0 | ● | |
| f368 | Analog output signal type (AO2) | f307 | 0 | ● | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---------------|-----------------|-----|--------------|
| f369 | Analog output function selection (AO2) | f348 | 0 | ○ | |
| f370 | Analog output current scaling (AO2) | 1~1280 | varies by model | ○ | |
| f371 | AO2 Analog output slope | f350 | 1 | ○ | |
| f372 | AO2 Analog output bias | F351 | 20 | ○ | |
| f373 | Analog Output current Bias Calibration (AO2) | 0~255 | varies by model | ○ | |
| f374 | Percentage of AO monitored values | 0~250% | 0 | ○ | |
| f375 | Relay 1 disconnect delay | 0~60.0s | 0.0 | ○ | |
| f376 | Relay 1 disconnect delay | 0~60.0s | 0.0 | ○ | |

6.1.5 F4 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---------------------------------|--|---------|-----|--------------|
| f400 | Number of automatic fault reset | 0: disabled 1~10: reset try times. | 0 | ● | |
| f401 | Motor overload characteristics | 0: Overload protection enabled, overload speed reduction disabled (normal motor) 1: Overload protection enabled, overload 2: speed reduction enabled (normal motor) 2: Overload protection disabled, overload speed reduction disabled (normal motor) 3: Overload protection disabled, overload speed reduction enabled (normal motor) 4: Overload protection enabled, overload speed reduction disabled (forced air cooling) 5: Overload protection enabled, overload speed reduction enabled (forced air cooling) 6: Overload protection disabled, overload speed reduction disabled (forced air cooling) 7 : Overload protection disabled, overload speed reduction enabled (forced air cooling) | 0 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|---|---------|-----|--------------|
| f402 | Motor 150%-overload time limit | 10-2400 s | 300 | ○ | |
| f403 | Emergency stop selection | 0: Coast stop 1: Slowdown stop 2: Emergency DC braking | 0 | ● | |
| f404 | Emergency braking time | 0.0-20.0 s | 1.0 | ○ | |
| f405 | Input phase failure detection | 0: Disabled 1: Enable | 0 | ● | |
| f406 | Output phase failure detection mode selection | 0: Disabled 1: At start-up (Only one time after power is turned on) 2: At start-up (each time) 3: During operation 4: At start-up + during operation 5: Detection of cutoff on output side | 0 | ● | |
| f407 | Under-load trip/alarm selection | 0: Alarm 1: fault | 0 | ○ | |
| f408 | Under-load detection current | 0~100% | 0.00 | ○ | |
| f409 | Under-load detection current hysteresis | 1~20% | 10 | ○ | |
| f410 | Under-load detection time | 0-255 s | 0 | ○ | |
| f411 | Over-torque trip/Over-current indication | 0: Over-torque alarm (70%) 1: Over-torque fault 2: Over-torque alarm (100%) 3: Over-current alarm (70%) 4: Over-current fault 5: Over-current alarm (100%) | 0 | ○ | |
| f412 | Over-torque detection | 0~250% | 130 | ○ | |
| f413 | Over-torque detection level hysteresis | 0~100% | 10 | ○ | |
| f414 | Over-torque detection time | 0.0~10.0 s | 0.5 | ○ | |
| f415 | Over-voltage limit operation | 0: Enabled. 1: Disabled 2: Enabled (Quick deceleration). 3: Enabled (Dynamic quick deceleration). | 2 | ● | |
| f416 | Over-voltage limit | 100-150% | 130 | ● | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|--|-----------------|-----|--------------|
| f417 | Under-voltage trip/alarm selection | 0: Alarm only (detection level below 60%) 1: Tripping (detection level below 60%). 2: Alarm only (detection level below 50%) | 0 | ● | |
| f418 | Instantaneous power failure coast stop selection | 0: disabled 1: factory reserved 2: Coast stop. | 0 | ● | |
| f419 | Forced fire-speed control function | 0: Disabled. 1: Enabled. | 0 | ○ | |
| f420 | Detection of output short-circuit during start-up | 0: Each time (standard pulse) 1: Only one time after power is turned on (standard pulse) 2: Each time (short-time pulse) 3: Only one time after power is turned on (short-time pulse) | 0 | ● | |
| f421 | Motor over-load retention selection | 0: disabled. 1: Enabled. | 0 | ○ | |
| f422 | AI1 input loss | 1~100% | 0 | ○ | |
| f423 | Activation of the VFD during 4-20mA signal loss | 0: No measures. 1: Coast stop. 2: switch to Fallback speed. 3: Speed maintaining. 4: Slowdown stop. | 0 | ● | |
| f424 | Fallback speed | 0.0 Hz ~f007 | 0.0 | ○ | |
| f425 | PTC thermal protection | 0: Disabled 1: Enabled (trip mode) 2: Enabled (alarm mode) | 0 | ○ | |
| f426 | Resistor value for PTC detection | 100-9999Ω | 3000 | ○ | |
| f428 | Cumulative operation time alarm setting | 0.0-999.9 h (0.1=10 hour) | 610.0 | ○ | |
| f429 | VFD trip retention selection | 0: clearing 1: maintaining | 0 | ○ | |
| f430 | Heat sink temperature reaches the alarm value | 0 ~100°C | varies by model | ● | |
| f431 | Analog output current scaling (AO1) | 1~1280 | varies by model | ○ | |
| f432 | Analog Output current Bias Calibration (AO1) | 0~255 | varies by model | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---------------|-----------------|-----|--------------|
| f433 | Analog output current scaling (AO2) | 1~1280 | varies by model | ○ | |
| f434 | Analog Output current Bias Calibration (AO2) | 0~255 | varies by model | ○ | |
| f435 | Runtime 2 (read-only) | 0~65535 | - | ● | |

6.1.6 F5 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|-----------------|-----|--------------|
| f500 | Flying start (Speed tracking at start) | 0: Disabled 1: At auto-restart after momentary stop 2: When turning standby (input terminal function =1) on or off 3: At auto-restart or when turning standby (input terminal function =1) on or off 4: At start-up 5~7: Factory reserved 8: DC braking and then start. DC braking current level and brake time according f507& f508 | 0 | ● | |
| f501 | auto-stop time limit for lower-limit frequency operation | 0.0: disable 0.1-600.0 s | 0.1 | ○ | |
| f502 | Bumpless operation selection | 0: disabled. 1: enabled. | 1 | ○ | |
| f503 | Starting frequency setting | 0.5~10.0 Hz | 0.5 | ○ | |
| f504 | Operation starting frequency | 0.0 Hz ~f007 | 0.0 | ○ | |
| f505 | Operation starting frequency hysteresis | 0.0 Hz ~f007 | 0.0 | ○ | |
| f506 | DC braking starting frequency | 0.0 Hz ~f007 | 0.0 | ○ | |
| f507 | DC braking current | varies by model | varies by model | ○ | |
| f508 | DC braking time | 0.0~20.0 s | 1.0 | ○ | |
| f510 | Acceleration/deceleration 1 pattern | 0: Linear 1: S pattern 1 2: S pattern 2 3: Elevator acceleration / deceleration curve | 0 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|---------|-----|--------------|
| f511 | Acceleration/deceleration 2 pattern | 0: Linear 1: S pattern 1 2: S pattern 2 | 0 | ○ | |
| f512 | Acceleration/deceleration 3 pattern | 0: Linear 1: S pattern 1 2: S pattern 2 | 0 | ○ | |
| f513 | Acceleration/deceleration 1 and 2 switching | 0.0 Hz ~f008 | 0.0 | ○ | |
| f514 | Acceleration/deceleration 2 and 3 switching | 0.0 Hz ~f008 | 0.0 | ○ | |
| f515 | Selecting an acceleration/deceleration pattern | 1: Acc/Dec 1 2: Acc/Dec 2 3: Acc/Dec 3 | 1 | ○ | |
| f516 | S-pattern lower-limit adjustment amount | 0~50% | 10 | ○ | |
| f517 | S-pattern upper-limit adjustment amount | 0~50% | 10 | ○ | |
| f518 | Acceleration time 2 | 0.0~3200 s | 20.0 | ○ | |
| f519 | Deceleration time 2 | 0.0~3200 s | 20.0 | ○ | |
| f520 | Acceleration time 3 | 0.0~3200 s | 20.0 | ○ | |
| f521 | Deceleration time 3 | 0.0~3200 s | 20.0 | ○ | |
| f522 | Reverse-run prohibition | 0: Forward/reverse run permitted. 1: Reverse run prohibited. 2: Forward run prohibited. | 0 | ● | |
| f523 | Stop type | 0: Ramp shutdown 1: Free shutdown of keyboard 2: 2 line control free stop 3: 2 line control free stop | 2 | ○ | |
| f526 | Forward and reverse priority setting | 0: Forward + Reverse ----->Reverse 1: Forward + Reverse ----->Stop 2: Forward + Reverse ----->pre-set direction 3: Forward + Reverse----->In the direction given by 4: Forward + Reverse----->Forward | 1 | ○ | |
| f527 | regenerative braking selection | 0: Disabled 1: Enabled (with resistor overload protection) 2: Enabled (without resistor overload protection) | 2 | | |
| f528 | regenerative braking resistance | 1.0~1000.0Ω | 20.0 | ● | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|---|---------|-----|--------------|
| f529 | regenerative braking resistor capacity | 0.01~30.0 kW | 0.12 | ● | |
| f530 | Positive and negative dead zone time | 0.0~25.0s | 0.0s | ○ | |
| f531 | HMI RS485 communication port Modbus protocol | 0~1 | 0 | ○ | |
| f532 | Input voltage monitoring value compensation | 0.0%~900.0% | 100% | ● | |
| f534 | Communication address E002H input current phase selection | 0: 1A 1: 0.1A 2: 0.01A | 2 | ○ | |
| f535 | PLC Preset speed direction | 0000H~FFFFH | 0000H | ● | |
| f536 | PLC speed direction selection | 0:PLC speed direction select as f748 1:PLC speed direction select as f535 | | ● | |
| f537 | 2-wire control mode 2 enabled | 0: disable 1:enable 2-wire control mode 2-Self - locking switch (Electrical level) controls positive and negative rotation 2:enable 2-wire control mode 2-button switch(pulse)controls positive and negative rotation | | ● | |

6.1.7 F6 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|---------|-----|--------------|
| f600 | Prohibition of panel reset operation | 0: Permitted 1: Prohibited | 0 | ○ | |
| f601 | Switching between remote control and Local control | 0: Local control mode 1: Remote control mode 2: Cooperate with f700 to set the function of JOG key | 1 | ○ | |
| f602 | Password check/input | 0~9999 | 0 | ○ | |
| f603 | Current/voltage/% display mode | 0: % 1: A (ampere)/V (volt), | 1 | ○ | |
| f604 | Frequency free unit magnification | 0: unit is Hz 0.01-200.0: free unit | 0.00 | ○ | |
| f605 | Arbitrary unit conversion selection | 0: Show as frequency unit 1: Change PID frequency to any unit | 0 | ● | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|---|-----------------|-----|--------------|
| f606 | Inclination characteristic of free unit display | 0: Negative inclination (downward slope) 1: Positive inclination (upward slope) | 1 | ○ | |
| f607 | Bias of free unit display | 0.00 Hz ~f007 | 0.00 | ○ | |
| f608 | Free step 1 (pressing a panel key once) | Disabled: 0.00 Enabled: 0.01 Hz~f007 | 0.00 | ○ | |
| f609 | Frequency resolution of the panel | 0: disabled 1~255: enabled | 0 | ○ | |
| f610 | Standard monitor display selection | 0: Output frequency(Hz(free)) 1: Frequency command(Hz(free)) 2:Output current(%/A) 3: VFD rated current (A) 4: VFD load (%) 5: Output power (kW) 6: Stator frequency (Hz (free)) 7: Communication data display 8: Output speed(rpm) 9: Communication counter 10: Normal communication counter 11: Stop - given frequency (f900=0)/given PID (f900 ≠0),Run - output frequency 12: Running speed(output frequency*f225) 13: Average speed (Average speed setting of multistage speed) 14: Multistage speed number (Current running segment speed number) 15: Running time 2 (not the cumulative running time) | 0 | ○ | |
| f611 | panel running order clear selection | 0: clear (When running order terminal off) 1: keep (When running order terminal off) | 1 | ○ | |
| f612 | Panel operation prohibition (f000) | 0: Permitted "up" or "down" button 1: Prohibited "up" or "down" button | 0 | ○ | |
| f613 | Prohibition of panel operation (RUN/STOP keys) | 0: Permitted. 1: Prohibition. | 0 | ○ | |
| f614 | Prohibition of panel emergency stop operation | 0: Permitted. 1: Prohibition. 2: No alarm during terminal emergency stop, panel emergency stop is enabled. 3: No alarm during terminal emergency stop, panel emergency stop is disabled. | 0 | ○ | |
| f616 | Integral output power retention selection | 0: (clear) 1: (memory) | 1 | ○ | |
| f617 | Integral output power display unit selection | 0: 1kWh. 1: 10kWh. 2: 100kWh. 3: 1000kWh. | varies by model | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---|---------|-----|--------------|
| f618 | Search and resetting of changed parameters selection | 0: disable 1: enable | 0 | ○ | |
| f619 | VFD internal temperature monitoring 1 | | | | |
| f620 | VFD internal temperature monitoring 2 | | | | |
| f621 | LCD contrast control | 15~40 | 25 | | |
| f622 | factory reserved | | | | |
| f623 | Bit0: Fan auto-running | 0: The fan works when the VFD is running 1. The fan works when the VFD is powered on | 0 | ○ | |
| | Bit1: Positive power monitoring | 0: Monitoring both positive and negative power 1: Monitor only positive power | | | |
| | Bit2:main display quickly monitoring | 0:disable 1:enable | | | |
| | Bit3:Forward and reverse dead time mode selection | 0:Forward and reverse dead time mode1 1:Forward and reverse dead time mode2 | | | |
| | Bit4: over current alarm | 0: Alarm 1: No alarm | | | |
| | Bit5:overvoltage alarm | 0: Alarm 1: No alarm | | | |
| | Bit6:overload alarm | 0: Alarm 1: No alarm | | | |
| | Bit7:overheat alarm | 0: Alarm 1: No alarm | | | |
| | Bit IGBT overheat current level calculation forbid | 0: Enable 1: Disable | | | |
| f624 | Keyboard panel displays 2 | Same as f610 | 2 | ○ | |
| | Quick Monitoring 1 | Same as f610 | | | |
| f625 | Keyboard panel displays 3 | Same as f610 | 1 | ○ | |
| | Quick Monitoring 2 | Same as f610 | | | |
| f626 | Keyboard panel displays 4 | Same as f610 | 5 | | |
| | Quick Monitoring 3 | Same as f610 | | | |
| f627 | Relay output -PID feedback check out | 0.00~99.99 | 0.00 | ○ | |
| f628 | Relay output -PID feedback to detect bandwidth | 0.00~99.99 | 0.00 | ○ | |
| f629 | Factory reserved | | - | ○ | |

6.1.8 F7 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|-------------------------------|---|---------|-----|--------------|
| f700 | JOG key function setting | 0~6 | 4 | ○ | |
| f701 | Jog frequency | 0.0~20.1Hz | 5.0 | ○ | |
| f702 | Jog stop mode | 0: Decelerating Stop 1: Free stop 2: DC Braking | 0 | ○ | |
| f703 | Jump frequency 1 | 0.0 Hz ~f007 | 0.0 | ○ | |
| f704 | Jumping width 1 | 0.0 ~30.0 Hz | 0.0 | ○ | |
| f705 | Jump frequency 2 | 0.0 Hz ~f007 | 0.0 | ○ | |
| f706 | Jumping width 2 | 0.0~30.0 Hz | 0.0 | ○ | |
| f707 | Jump frequency 3 | 0.0 Hz ~f007 | 0.0 | ○ | |
| f708 | Jumping width 3 | 0.0~30.0 Hz | 0.0 | ○ | |
| f709 | Braking mode selection | 0~3 | 0 | ● | |
| f710 | Release frequency | f503~20.0Hz | 3.0 | ○ | |
| f711 | Release time | 0~25.0s | 0.5 | ○ | |
| f712 | Creeping frequency | f503~20.0Hz | 3.0 | ○ | |
| f713 | Creeping time | 0~25.0s | 1.0 | ○ | |
| f714 | Droop gain | 0~100% | 0 | ○ | |
| f715 | Droop insensitive torque band | 0~100% | 10 | ○ | |
| f716 | Preset-speed 1 | f009~f008 | 3.0 | ○ | |
| f717 | Preset-speed 2 | f009~f008 | 6.0 | ○ | |
| f718 | Preset-speed 3 | f009~f008 | 9.0 | ○ | |
| f719 | Preset-speed 4 | f009~f008 | 12.0 | ○ | |
| f720 | Preset-speed 5 | f009~f008 | 15.0 | ○ | |
| f721 | Preset-speed 6 | f009~f008 | 18.0 | ○ | |
| f722 | Preset-speed 7 | f009~f008 | 21.0 | ○ | |
| f723 | Preset-speed 8 | f009~f008 | 24.0 | ○ | |
| f724 | Preset-speed 9 | f009~f008 | 27.0 | ○ | |
| f725 | Preset-speed 10 | f009~f008 | 30.0 | ○ | |
| f726 | Preset-speed 11 | f009~f008 | 33.0 | ○ | |
| f727 | Preset-speed 12 | f009~f008 | 36.0 | ○ | |
| f728 | Preset-speed 13 | f009~f008 | 39.0 | ○ | |
| f729 | Preset-speed 14 | f009~f008 | 45.0 | ○ | |
| f730 | Preset-speed 15 | f009~f008 | 50.0 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|--|---------|-----|--------------|
| f731 | factory reserved | - | | | |
| f732 | Multi-speed 0 run time | 0~65000.0s(min) | 0.0 | ● | |
| f733 | Multi-speed 1 run time | 0~65000.0s(min) | 0.0 | ● | |
| f734 | Multi-speed 2 run time | 0~65000.0s(min) | 0.0 | ● | |
| f735 | Multi-speed 3 run time | 0~65000.0s(min) | 0.0 | ● | |
| f736 | Multi-speed 4 run time | 0~65000.0s(min) | 0.0 | ● | |
| f737 | Multi-speed 5 run time | 0~65000.0s(min) | 0.0 | ● | |
| f738 | Multi-speed 6 run time | 0~65000.0s(min) | 0.0 | ● | |
| f739 | Multi-speed 7 run time | 0~65000.0s(min) | 0.0 | ● | |
| f740 | Multi-speed 8 run time | 0~65000.0s(min) | 0.0 | ● | |
| f741 | Multi-speed 9 run time | 0~65000.0s(min) | 0.0 | ● | |
| f742 | Multi-speed 10 run time | 0~65000.0s(min) | 0.0 | ● | |
| f743 | Multi-speed 11 run time | 0~65000.0s(min) | 0.0 | ● | |
| f744 | Multi-speed 12 run time | 0~65000.0s(min) | 0.0 | ● | |
| f745 | Multi-speed 13 run time | 0~65000.0s(min) | 0.0 | ● | |
| f746 | Multi-speed 14 run time | 0~65000.0s(min) | 0.0 | ● | |
| f747 | Multi-speed 15 run time | 0~65000.0s(min) | 0.0 | ● | |
| f748 | PLC speed direction option | 0000H-FFFFH | 0000H | ● | |
| f749 | Simple PLC running mode | 0: run one time and then stop 1: run one time and keep running at the final value 2: recycle running | 0 | ● | |
| f750 | Simple PLC restart mode selection | 0: start running from the first phase 1: keep running from the interrupt frequency | 0 | ● | |
| f751 | Simple PLC Power drop memory selection | 0: no memory for power drop 1: memory for power drop | 0 | ● | |
| f752 | Simple PLC running time unit selection | 0: second (s) 1: minute (min) | 0 | ● | |
| f753 | Nonstandard function selection | 0: Standard functions 1~65535: Nonstandard functions | 0 | ○ | |
| f754 | AI1 curve selection | 0: Curve (Point 2) 1: Curve (Point 4) | 0 | ○ | |
| f755 | AI1 curve 2 set point 1 input | 0.0 ~ 100.0% | 0.0% | ○ | |
| f756 | AI1 curve 2 sets point 1 output | -100% ~ 100% | 0.0% | ○ | |
| f757 | AI1 curve 2 set point 2 input | 0.0 ~ 100.0% | 30.0% | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---------------------------------|----------------|---------|-----|--------------|
| f758 | AI1 curve 2 sets point 2 output | -100% ~ 100% | 30.0% | ○ | |
| f759 | AI1 curve 2 set point 3 input | 0.0 ~ 100.0% | 60.0% | ○ | |
| f760 | AI1 curve 2 sets point 3 output | -100% ~ 100% | 60.0% | ○ | |
| f761 | AI1 curve 2 set point 4 input | 0.0 ~ 100.0% | 100.0% | ○ | |
| f762 | AI1 curve 2 sets point 4 output | -100% ~ 100% | 100.0% | ○ | |
| f763 | LI1 effective delay | 6500.0 ~ 0.0 s | 0.0 | ○ | |
| f764 | LI1 invalid delay | 6500.0 ~ 0.0 s | 0.0 | ○ | |
| f765 | LI2 effective delay | 6500.0 ~ 0.0 s | 0.0 | ○ | |
| f766 | LI2 invalid delay | 6500.0 ~ 0.0 s | 0.0 | ○ | |
| f767 | AI1 filtering coefficient | 0.00 -10.00 | 0.30 | ○ | |
| f768 | AI2 filtering coefficient | 0.00 -10.00 | 0.30 | ○ | |
| f769 | AO1 filtering coefficient | 0.00 -10.00 | 0.00 | ○ | |
| f771 | Foreward Jog frequency | 0.0HZ -f007 | 0.00 | ○ | |
| f772 | Password Setting | 0~9999 | 0 | ○ | |
| f773 | Password duration | 0~9999 min | 5 | ○ | |

6.1.9 F8 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|---|--|---------|-----|--------------|
| f800 | Modbus baud rate | 0: 9600 bps 1: 19200 bps 2: 4800 bps 3: 2400 bps 4: 1200 bps | 1 | ○ | |
| f801 | Modbus parity | 0: None 1: Even 2: Odd | 1 | ○ | |
| f802 | Modbus address | 0-247 | 1 | ○ | |
| f803 | Modbus timeout | 0: Timeout check disabled. 1-100s: Communication timeout | 0 | ○ | |
| f804 | Modbus transfer waiting time | 0~2.00 s | 0.00 | ○ | |
| f805 | Modbus behaviour on communication fault | 0: VFD stop, communication command, frequency mode open (by f002, f003) 1: None (continued operation) 2: Deceleration stop 3: Coast stop 4: Communication error (e-33 trip) or Network error (e-35 trip) | 4 | ○ | |

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|---------------|---|--|---------|-----|--------------|
| f806 | Number of motor poles for communication | 2~16 | 2 | ○ | |
| f813 | Write data 1 | 0: No select | 0 | ○ | |
| f814 | Write data 2 | 1: Communication commend control (fa05) 2: Reserved 3: Communication commend control(fa08) 4-6: reserved | 0 | ○ | |
| f815 | Read data 1 | 0: No select | 1 | ○ | |
| f816 | Read data 2 | 1: state data (fd03) | 2 | ○ | |
| f817 | Read data 3 | 2: Output frequency (fd12) | 12 | ○ | |
| f818 | Read data 4 | 3: output current (fe08) 4: Output voltage (fe10) | 18 | ○ | |
| f819 | Read data 5 | 5: Fault data (fc39) 6: PID feedback (fa36) 7: input terminal data (fd01) 8: output terminal data (fd02) 9: AI1 input (fe30) 10: AI2 input (fe31) 11: Motor speed (fe50) 12: Absolute value of output current (e002) ,unit 0.01A 13: Absolute value of output voltage (e006) , unit V 14: Absolute value of output voltage of DC bus (e009), unit V 15: PID Given value (fa35) 16: output torque(fe20) ,0.01% of unit motor rated torque 17: input power (fe28) , unit 0.01kW 18: output power (fe29) , unit 0.01kW 19:Input power accumulation/ input power (FE44) ,see f617 20: output power accumulation / output power (fe45) , Unit see f617 21: running time accumulation (FE17) unit h (hour) | 8 | ○ | |
| f821~ f829 | Factory reserved | - | - | | |
| f830 | PID keyboard setting | 0~100% | 0.0 | ○ | |

6.1.10 F9 Group

| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---|-----------------|-----|--------------|
| f900 | PID control setting | 0: Disabled, 1: Enabled (Feedback: AI1) 2: Enabled (Feedback: AI2) | 0 | ○ | |
| f901 | PID Proportional gain (P control) | 0.01~100.0 | varies by model | ○ | |
| f902 | PID Integral gain (I control) | 0.01~100.0 | varies by model | ○ | |
| f903 | PID Differential gain(D control) | 0.00~2.55 | 0.00 | ○ | |
| f904 | PID control waiting time | 0~2400 s | 0 | ○ | |
| f905 | PID regulator deviation input signal negation/Direction | 0: disable/Direct action 1: enable/Reaction | 0 | ○ | |
| f906 | Sleep mode awakening hysteresis bandwidth | 0.0 Hz ~f007 | 0.2 | ○ | |
| f907 | When f917≠0.00,Sleeping mode awakening deviation(absolute value) | 0.00~f917 MPa | 0.00 | ○ | |
| | When f917=0.00, based on PI error value sleeping mode awakening PI threshold value | 0.0~f007Hz | 0.0 | ○ | |
| f908 | When f917≠0.00,Sleeping mode awakening threshold value (absolute value) | 0.0 Hz ~f917MPa | 0.00 | ○ | |
| | When f917=0.00, based on PI error value sleeping mode awakening PI threshold value | 0.0~f007Hz | 0.0 | ○ | |
| f909 | sleeping mode action | 0: Motor slowdown to a stop. 1: Motor keep running at lower limit frequency. | 0 | ● | |
| f910 | wake up/ delay control time | 0~600.0s | 0.0 | ● | |
| f911 | When f917≠0.00, Sleeping mode awakening threshold value (Percent) | 0~200.0% | 0.0 | ○ | |
| | When f917=0.00, Sleeping mode awakening pressure percent | 0~100% | 0.0 | ○ | |
| f912 | When f917≠0.00, Sleeping mode awakening threshold value (Percent) | 0~200.0% | 0.0 | ○ | |
| | When f917=0.00, Sleeping mode awakening pressure percent | 0~100% | 0.0 | ○ | |
| f913 | Upper limit of PID setting | 0~100% | 100 | ● | |
| f914 | Lower limit of PID setting | 0~f913 | 0 | ● | |
| f915 | Delay control of sleep mode | Disable: 0.0 Enable: 0.1-600.0 s | 0.1 | ○ | |
| f916 | When f917≠0.00, PID given control deviation | 0~100% | 0.0 | ○ | |
| | When f917=0.00,PID keyboard given | 0~100% | 0.0 | ○ | |










| NO. | Parameter Name | Setting Range | Default | WRT | User setting |
|------|--|---------------|---------|-----|--------------|
| f917 | Sensor range (When f917≠0.00,PID setting adopt absolute value.PID's keyboard adjustment is f918. f917=0.00,PID setting adopt percent, PID's keyboard adjustment is f916. | 0.00~99.99 | 1.00 | ○ | |
| f918 | PID adjustment | 0.00~f917 | 0.00 | ○ | |
| f919 | Sleeping frequency | F009~f008 | F009 | ○ | |
| f920 | Sleeping threshold tolerance | 0.0~25.0% | 0.0 | ○ | |



Note 1: in the volume of '○': means writable at stop or running status, '●': means unwritable at stop or running status;

Note 2: we can obtained modbus parameter address by replacing 'F'to '0'. E.g. f908's address is 0x0908

Note 3: Common user parameter power-off does not save the communication address. F is reserved, that is, the communication address is the same as the parameter number. For example, the communication address of f908 is 0xf908.

6.1.11 U0 Group

| NO. | Parameter Name | Description |
|------|----------------------------------|---|
| u000 | CPU1 Version | E.g:  , G type: v=g,P type: v=p. |
| u001 | Operation frequency | Value is displayed in Hz/free unit. See f604. |
| u002 | Direction of rotation |  Forward run,  Reverse run. |
| u003 | Frequency command value | Value is displayed in Hz/free unit. See f604. |
| u004 | Load current | The VFD output current (%/A) is displayed. |
| u005 | Input voltage (AC RMS) | The VFD input voltage (%/V) is displayed. |
| u006 | Output voltage (AC RMS) | The VFD output voltage command (%/V) is displayed. |
| u007 | Input terminal status indicated | <p>11kW and below:  : OFF  : ON</p> <p>15kW and above:  : OFF  : ON</p> |
| u008 | Output terminal status indicated |  : OFF  : ON |
| u009 | Cumulative operation time | (0.01=1 hour, 1.00=100 hours) |

| NO. | Parameter Name | Description |
|------|--|---|
| u010 | Output speed | Displays the motor speed (min-1) by calculating with output frequency and pole numbers. |
| u011 | Rated current | The rated current of the VFD (A) is displayed. |
| u012 | Torque current | The torque current (%/A) is displayed. |
| u013 | Load current | The VFD output current (load current) (%/A) is displayed. |
| u014 | Torque | The torque (%) is displayed. |
| u015 | Input power | The VFD input power (kW) is displayed. |
| u016 | Output power | The VFD output power (kW) is displayed. |
| u017 | PID feedback | The PID feedback value is displayed. (Hz/free unit) |
| u018 | Frequency command value (PID-computed) | The PID-computed frequency command value is displayed. (Hz/free unit) |
| u019 | Integral input power | The integrated amount of power (kWh) supplied to the VFD is displayed. |
| u020 | Integral output power | The integrated amount of power (kWh) supplied from the VFD is displayed. |
| u021 | Communication counter | Displays the counter numbers of communication through the network. |
| u022 | Normal state communication counter | Displays the counter numbers of communication only at normal state in the all communication through network. |
| u023 | HMI version | Example:  |
| u024 | Parts replacement alarm information |  <p>ON: The maintenance time is up. It is recommended to replace the components</p> |
| u025 | Factory Reserve | |
| u026 | When f917=0.00; given pressure percent | When under PID control, given pressure percent monitor |
| | When f917≠0.00, given pressure absolute value | When under PID control, given pressure absolute value monitor (1.00=1.00Mpa=10kg/cm2) |
| u027 | When f917=0.00, feedback pressure percent | When under PID control, feedback pressure percent monitor |
| | When f917≠0.00, feedback pressure absolute value | When under PID control, feedback pressure absolute value monitor (1.00=1.00Mpa=10kg/cm2) |
| u1-- | Past trip 1 | Enter into the display of detailed information on past trip 1 |
| u2-- | Past trip 2 | Enter into the display of detailed information on past trip 2 |
| u3-- | Past trip 3 | Enter into the display of detailed information on past trip 3 |
| u4-- | Past trip 4 | Enter into the display of detailed information on past trip 4 |

7 Fault Diagnosis and Measures

7.1 Fault Code, course and measures

When fault (failure) occurs, the VFD takes the following actions: The keyboard panel blinks to display the fault code, the VFD stops output and the motor freely stops.

Table 7.1 Fault display and measures

| Code of fault | Type of fault | Possible cause | Measures (troubleshooting) |
|---------------|-------------------------|---|---|
| e-01 | Overcurrent protection | <ul style="list-style-type: none"> Acceleration time is too short. V/f parameter is wrongly set. When the VFD starts, the load is still in rotation. VFD is supplying power to low-impedance motor. IntePhase short circuit or earthing failure. Abrupt fluctuation of the load | <ul style="list-style-type: none"> Increase acceleration parameter (f010 or f618) and the deceleration time (f011 or f519) Select the correct setpoint for V/f. Adopt forward/reverse speed tracking and restart function (STR function). Tune the switching frequency. Check wiring to see if there is Intephase short circuit or earthing failure. Reduce fluctuation of the load |
| e-02 | IntePhase short circuit | <ul style="list-style-type: none"> InterPhase output is short circuit. Motor impedance is too low. | <ul style="list-style-type: none"> Confirm the wiring and insulation status. |
| e-03 | Starting overcurrent | <ul style="list-style-type: none"> Grounding fault IGBT unit damage | <ul style="list-style-type: none"> Confirm whether the wiring and device are earthing Connect with factory |
| e-04 | Grounding fault | <ul style="list-style-type: none"> Grounding fault IGBT unit damage | <ul style="list-style-type: none"> Confirm whether the wiring and device are earthing Connect with factory |
| e-06 | Underload fault | <ul style="list-style-type: none"> VFD's output current is lower than low current detection threshold. | <ul style="list-style-type: none"> Check whether f407~f410 are correctly set. |
| e-07 | Overtorque fault | <ul style="list-style-type: none"> The motor estimates that the torque has reached the level set by f412. | <ul style="list-style-type: none"> Adjust the settings of f411~f414. Confirm the load status. |

| Code of fault | Type of fault | Possible cause | Measures (troubleshooting) |
|---------------|-----------------------------|--|--|
| e-11 | Undervoltage fault | <ul style="list-style-type: none"> Abnormal fluctuation of input voltage; Power network capacity higher than 200 kVA; There is switchable capacitor to improve power factor on the power network; SCRs is connected to the power network. VFD starts the load already in rotation. There is possible phase failure. The deceleration time is too short. | <ul style="list-style-type: none"> Install input reactor or use braking resistance. Adopt forward/reverse speed tracking and restart function (STR function) (f500 = 1) Set f418 = 2. Determine the cause of output phase failure (such as poor connection, open circuit of output or open circuit of motor winding) and correct it. Increase the deceleration time (f011 or f519) Adopt overvoltage protect(f415) |
| e-12 | DC bus undervoltage fault | <ul style="list-style-type: none"> Input voltage is too low. | <ul style="list-style-type: none"> Check input voltage. Set f417 to select alarm or tripping. Adopt forward/reverse speed tracking and restart function (STR function) (f500 = 1) Set f418= 2. |
| e-21 | VFD overload | <ul style="list-style-type: none"> Acceleration time is too short. DC braking current level is too high. V/f parameter is wrongly set. When the VFD starts, the load is still in rotation. The load is too large. | <ul style="list-style-type: none"> Increase acceleration parameter f010 or f518). Decrease the setting of f507 or f508. Correctly set V/f parameter. Set parameter f418 = 2. Adopt one VFD with higher rated power. |
| e-22 | Motor overload | <ul style="list-style-type: none"> V/f parameter is wrongly set. The motor is blocked. The motor continues to run at low speed. The load applied to the motor is too large. | <ul style="list-style-type: none"> Correctly set V/f parameter. Check the load. |
| e-23 | Braking resistor overload | <ul style="list-style-type: none"> Improper specification selection for braking resistor | <ul style="list-style-type: none"> Select competent braking resistor. Prohibit braking resistor overload protection f527=2 |
| e-24 | VFD overheat fault | <ul style="list-style-type: none"> VFD 's cooling fan does not work. Environment temperature is too high. Certain ventilation opening is blocked. There is heat source near the VFD . | <ul style="list-style-type: none"> Reset the VFD 's fault after cooling and restart the VFD Expand the free space around the VFD ; Remove all heat sources near the VFD to lower the environment temperature. |
| e-25 | Motor PTC overheating fault | <ul style="list-style-type: none"> External PTC embedded in the motor winding indicates existence of motor overheating. | <ul style="list-style-type: none"> Correct motor overheating. Check whether PTC is working properly. Check logic input functions 27 and 28. |

| Code of fault | Type of fault | Possible cause | Measures (troubleshooting) |
|---------------|--------------------------------|--|--|
| e-31 | EEPROM fault | <ul style="list-style-type: none"> Data writing and read errors occur. The VFD has power failure during parameter reset. | <ul style="list-style-type: none"> Power on the VFD to eliminate the fault. If the fault can not be eliminated, contact us or our distributor for maintenance or repair of the VFD. |
| e-32 | Control board fault | <ul style="list-style-type: none"> Control board cannot work | <ul style="list-style-type: none"> Connect manufacturer to maintain |
| e-33 | Communication fault | <ul style="list-style-type: none"> Network communication error. | <ul style="list-style-type: none"> Check network control devices and cables. Check the setting of communication overtime parameter f803. Check remote keyboard panel cable. |
| e-34 | Current sensor fault | <ul style="list-style-type: none"> The current sensor is in abnormal status. | <ul style="list-style-type: none"> Replace the VFD. |
| e-35 | Network fault | <ul style="list-style-type: none"> Network error | <ul style="list-style-type: none"> Check network control devices and cables. |
| e-36 | VFD type error | <ul style="list-style-type: none"> VFD hardware fault | <ul style="list-style-type: none"> f120=7 If error is still, connect manufacturer to maintain |
| e-38 | AI1 signal Loss | <ul style="list-style-type: none"> AI1 analog signal level is lower than the level set by the parameter f422. | <ul style="list-style-type: none"> Check signal on AI1 to eliminate the cause of signal loss. Confirm whether f422 is correctly set. |
| e-39 | VFD inside communication error | <ul style="list-style-type: none"> Communication error between keyboard and control board CPU | <ul style="list-style-type: none"> Connect manufacturer to maintain |
| e-42 | Output phase failure | <ul style="list-style-type: none"> The output side of the main circuit is phase failure. | <ul style="list-style-type: none"> Determine the cause of input phase failure (such as poor connection, open circuit of output or open circuit of motor winding) and correct it. Set f406 = 0. |
| e-43 | Emergency stop fault | <ul style="list-style-type: none"> Use the keyboard panel to perform stop operation when the motor works under remote mode. | <ul style="list-style-type: none"> Perform fault reset. |
| e-45 | Torque boost is too large | <ul style="list-style-type: none"> Setting of torque boost parameter f203 is too high. Motor impedance is too low. | <ul style="list-style-type: none"> Vector control mode: Repeat self-tuning of the VFD and downward tune parameter f203. V/F mode: downward tune parameter f202. |

| Code of fault | Type of fault | Possible cause | Measures (troubleshooting) |
|---------------|--|--|--|
| e-46 | Self-setting error | <ul style="list-style-type: none"> • Confirm whether motor rated parameter settings are correct. • The motor capacity is far smaller than that of the VFD . • Cable of the motor is too thin. • Motor is still in rotation when the self-setting starts. | <ul style="list-style-type: none"> • Correctly set motor rated parameters. • Use VFD with larger capacity. • Apply thicker cable of the motor. • Confirm the motor has stopped before the self-setting begins. |
| e-98 | External panel communication failure | Communication error between the external panel and the internal CPU. | Check whether the external lead panel is connected to the lower network port (reliably connected next to the 485 terminal) and whether 485 is connected to the MDBUS communication network cable. If the network cable cannot be connected, replace it with a new one and contact the manufacturer to repair the inverter. |
| e-99 | High power display board communication failure | Communication error between the display panel and the internal CPU of inverters above 15kW (inclusive). | Check whether the panel and the APP Internet port are connected reliably. If the network cable cannot be connected, replace it with a new one and contact the manufacturer to repair the inverter. |

7.2 Description of alarm and indication code

Table 7.2 Alarm display and measures

| Code | Description | Cause | Measures |
|-------------|--|---|---|
| a-00 | Fault reset is acceptable. | Under fault code display state, press STOP key and a-00 is displayed. | Press the STOP key again and the fault is eliminated. |
| a-01 | Undervoltage indication | Insufficient input voltage | Check the single-phase input power supply. If the power supply is normal, the VFD has to be repaired. |
| 0.0 (flash) | "Running ready" is invalid | Under remote control mode the corresponding terminal to the logic input function 1 is not closed. | Configure one logic input function as 1 (include f309, f310) , and close this terminal. |
| a-05 | Abnormal setting of frequency point | Frequency points at point 1 and point 2 are set too closely. | Do not set f325 and f327 too closely. Do not set f329 and f331 too closely. |
| a-06 | Free stop action during transient power failure. | f418 is set to 2 and transient power failure occurs. | Input running signal to the VFD again or reset the VFD . |

| Code | Description | Cause | Measures |
|------|---|---|---|
| a-07 | In DC braking | DC braking function is activated. | If the code disappears in several seconds, the VFD comes back to normal. |
| a-08 | In running retrial | The VFD is in the process of restart. Forward/reverse speed tracking and restart function (STR function) is activated. | The alarm code is momentarily displayed then disappears, and the VFD restarts. |
| a-10 | In low speed sleep | See parameter f501. | Disabled This function or raise the frequency instruction to f009+f906. |
| a-11 | Key fault on the keyboard | Certain key on the keyboard panel is continuously pressed more than 20 s or the panel is damaged. | If all keys are released but the alarm does not disappear, the VFD has to be repaired. |
| a-12 | In the process of parameter initialization | See parameter f120. | If the alarm code is momentarily displayed and then disappears, the VFD comes back to normal. |
| a-13 | Loss of analog signal | Analog input terminal detection level is lower than the setting level of f422. | Check analog input terminal |
| e1 | Exceeding displayed digit number by 1 digit | Displayed digit number exceeds 4 digits. | Try to reduce the set-point of f604 |
| eun1 | In the process of self-setting | VFD is performing self-setting. | If the alarm code is momentarily displayed and then disappears, the VFD comes back to normal. |

Table 7.3 Display of early warning code

| Code | Type | Description |
|------|----------------------------|--|
| ---c | Over current early warning | VFD is in current amplitude limiting state. See parameters f107 and f111. |
| --u- | Over voltage early warning | VFD approaches over voltage fault. See parameters f415 and f416. |
| -l-- | Overload early warning | This code is displayed when the motor or VFD overload counter exceeds 50%. |
| h--- | Overheat early warning | VFD approaches overheat fault. |

Note: Early warning types can occur simultaneously. E.g, when overheat early warning and over current early warning happen in the same time, the corresponding code is h--c.

7.3 Restart of the VFD after fault occurs

After failure occurs in the VFD , it can be restarted only when the cause of the failure has been eliminated. Please follow the undermentioned operations to realize fault reset of the VFD .

(1) After the defect is eliminated, press STOP on the keyboard, display show a-00, press STOP again, VFD fault reset, then can supply power to the motor.

(2) When the VFD is under remote control mode and f002 = 0, set the input function configuration of any logic input terminal to 10. Then the VFD can use this terminal to perform fault reset.

(3) When the VFD is under remote control mode and f002 = 2, fault reset is realized through remote communication devices. See Appendix A: Serial communication.

(4) Switch off the VFD and power it on again

Note: When the fault is motor overload or VFD overload (e-21 or e-22), VFD reset function can not be performed if computed cooling time is not up. The computed cooling time is specified as: e-21, 30 seconds after the fault occurs; e-22, 120 seconds after the the fault occurs.

Appendix A: Serial Communication

Serial communication is the information exchange channel of the VFD with upper computer. Through serial communication, users can use personal computer or industrial control equipment (such as PLC etc) as host to set VFD (slave)'s running frequency or command, modify or read data, read working state and fault information etc and realize remote or centralized control of the VFD .

RVE32 series VFD adopt RS-485 bus and Modbus protocol for serial communication.

A1. RS485 Bus

The hardware circuit of serial communication for Variable Frequency Drive follows RS-485 standard and a RJ45 interface is provided. Here RS-485 two-wire wiring method is adopted. The array sequence of the corresponding pins of RJ45 interface is shown as below:




Figure A.1 RJ45 front view

Table A.1 Pin output signal allocation

| Pin | Signal description |
|-----|--|
| 1 | Reserved |
| 2 | Common port (signal ground & power ground) |
| 3 | Reserved |
| 4 | A (RS-485) |
| 5 | B (RS-485) |
| 6 | Reserved |
| 7 | +24 V |
| 8 | Common port (signal ground & power ground) |

RS-485 two-wire wiring method supports bus-type topological structure. At most 32 nodes can be connected to the same bus. Normally master-slave communication method is adopted in the RS-485 communication network, namely, one master commands as many as 31 slaves.

Under the circumstance of multi-computer communication or long-distance communication, it is suggested to connect the signal ground of the master station with the common port of the VFD to raise the ant-interference ability of communication.

A2. Modbus protocol

Modbus is a master-slave communication protocol. The master governs the whole communication process. Only when the master sends command to the slave, the slave executes the actions or/and send feedback information to the master. Otherwise the slave performs no operation and the slave can not communicate with each other directly.

There are two kinds of dialogues between the master and slaves:

(1) Point-to-point: Master sends command individually to a certain slave which executes action or/and sends feedback information.

When the master command is correct, the slave executes corresponding actions and transmits feedback of result information to the master.

When the master command is false, the slave transmits feedback of error information to the master but executes no actions.

(2) Broadcast mode: The master sends command to all slaves which execute action but send no feedback information.

Modbus protocol has two kinds of transmission patterns: Modbus RTU and Modbus ASCII. RVE32 series VFD supports Modbus RTU.

A2.1 Description of Modbus-RTU message format

When the Modbus-RTU mode is used for communication, the communication information (message) is represented directly with hexadecimal code (1-9, A-F). Two hexadecimal codes form one byte. The message format is shown as below:




Figure A.2 Modbus Message Format

As shown in Figure A.2, during the communication process, the master and slave determine the start and end of Modbus message according to time interval of at least 3.5 characters. The message includes the complete data information to be transmitted: in the sequence of slave address, command code, data and CRC code. Its length varies with the change of the command code.

The message of Modbus-RTU is classified into three types and two formats:

1. Request (Interrogation) message: Command request message transmitted by master to slave;
2. Normal response message: The slave's feedback message when the master's command is correct.
3. Error response message: The slave's feedback message when the master's command is false / invalid.

Please find Table A.2 to check the details of Modbus-RTU message.

Table A.2 Instruction of Modbus-RTU message

| Number | Name | Function |
|--------|---------------|---|
| 1 | Slave address | <ul style="list-style-type: none"> Configured from 0 to 247 When master checking, if slave address set as 0, All slaves execute command but provide no feedback information; If slave address is set to 1~247, the dialog is point-to-point mode. All address-matching slaves execute command and provide feedback information. Under the point-to-point mode, when the matching slave responses, it sends back the slave address of itself. |
| 2 | Command code | <ul style="list-style-type: none"> This VFD supports part of command codes of Modbus protocol. All slaves execute command code and the matching slave responses code include: <ul style="list-style-type: none"> (1) 03H:Read one word (2 bytes) (2) 06H:Write one word (2 bytes) During error response, the feedback command code of the slave = the request command code of the master + 80H. |
| 3 | Data | <ul style="list-style-type: none"> This part is the main content of communication and the core of data exchange. Its content and length vary with the variation of the command codes. See the following concrete descriptions of every command code. |
| 4 | CRC code | <ul style="list-style-type: none"> Cyclical redundancy check (CRC) code is used for error detection of received data done by the receiving equipment and for judging whether the received data are correct. Please refer to "A2.3 Cyclical redundancy check (CRC)" for generation of CRC code. <p>Note: CRC code first sends low bytes then high bytes. Except this, all messages of Modbus-RTU adopt the transmission sequence of "high bytes first - then low bytes" .</p> |

A2.2 Detailed message description of different commands

A2.2.1 Read N words (2*N bytes) -- command code 03H

1. Master request message

Table A.3 Command code 03H host query message format

| Slave address | Command code | Communication address | | Read word number | | CRC code | |
|---------------|--------------|-----------------------|----------|------------------|----------|----------|-----------|
| 1 byte | 1 byte | 2 bytes | | 2 bytes | | 2 bytes | |
| | | High byte | Low byte | High byte | Low byte | low byte | high byte |
| | 03H | | | | | | |

1) Slave address and CRC code: See "Table A.2" .

2) Command code: 03H, request to read N words (2*N bytes) of the slave machine. Notice that N is at most 5.

3) Communication address: The address of read data. This is not the real physical address for data storage, but a number corresponding to the data. Every control, state or monitoring parameter of RVE32 series VFD corresponds to a communication address. See "A2.5 Communication parameter" .

4) Read word number: The length of the read data with the word (2 bytes) as the count unit. When current request asks for reading one word, it is set to 0001H.

2. Message of slave normal response

Table A.4 Command code 03H of slave machine normal reply message

| Slave address | Command code | Read bytes number | Read bytes number 2 | | ... | Read bytes number N | | CRC code | |
|---------------|--------------|-------------------|---------------------|----------|-----|---------------------|----------|----------|-----------|
| 1 byte | 1 byte | 1 byte | 2 bytes | | ... | 2 bytes | | 2 bytes | |
| | | | High byte | Low byte | ... | High byte | Low byte | Low byte | High byte |
| | 03H | | | | ... | | | | |

1) Slave address and CRC code: See "A2" .

2) Command code: 03H. The same as the master request command code.

3) Read word number: The length of the read data with byte as the count unit. When current master requests to read one word, set read byte number transmitted from the slave to 02H.

Note: The count unit of the length of the read data is different from that of request message.

4) Read data: Data corresponding to the communication address in the request message. Note: Read data firstly sends high byte then low byte in an opposite direction to CRC code.

3. Slave error response message

Table A.5 Slave error response message of Command code 03H

| Slave address | Command code | Error code | CRC code | |
|---------------|--------------|------------|----------|-----------|
| 1 byte | 1 byte | 1 byte | 2 bytes | |
| | | | Low byte | High byte |
| | 83H | | | |

1) Slave address and CRC code: See "A2" .

2) Command code: 83H. It is = 03H + 80H.

3) Error code. For detail see "A2.4 Error code" .

4) Example: Read upper limit frequency.

Master request message: 01 03 00 08 00 01 05 C8

Normal response message: 01 03 02 13 88 B5 12 (Suppose that current upper limit frequency is 50 Hz)

Error response message: 01 83 03 01 31 (Suppose that read word number is altered from 0001 to FFFF)

A2.2.2 Write one word (2 bytes) — Command code 06H

1. Master request message

Table A.6 Format of master request message

| Slave address | Command code | Communication address | | Write data | | CRC code | |
|---------------|--------------|-----------------------|----------|------------|----------|----------|-----------|
| 1 byte | 1 byte | 2 bytes | | 2 bytes | | 2 bytes | |
| | | High byte | Low byte | High byte | Low byte | Low byte | High byte |
| | 06H | | | | | | |

1) Slave address and CRC code: See "Table A.2" .

2) Command code: 06H. Request to write 1 word (2 bytes) of the slave.

- 3) Communication address: The address of read data. This is not the real physical address for data storage, but a number corresponding to the data. Every control, state or monitoring parameter of VFD corresponds to a communication address. See "A2.5 Communication parameter" .
- 4) Write data: Request data written by the slave.

A2.2.3 Write more word (2*N bytes) — Command code 10H

1. Master request message

Table A.7 Command 10H: Format of master request message

| Slave Address | Command code | Communication address | | Write data | | Write byte | Write data1 | | ... | Write data N | | CRC code | |
|---------------|--------------|-----------------------|----------|------------|----------|------------|-------------|----------|-----|--------------|----------|----------|-----------|
| 1byte | 1byte | 2byte | | 2byte | | 1byte | 2byte | | ... | 2byte | | Low byte | High byte |
| | 10H | High byte | Low byte | High byte | Low byte | | High byte | Low byte | ... | High byte | Low byte | | |

- 1) Slave address and CRC code: See "Table A.2" .
- 2) Command code: 10H. Request to write N word (2*N bytes) of the slave.,note N≥5
- 3) Communication address: The address of read data. This is not the real physical address for data storage, but a number corresponding to the data. Every control, state or monitoring parameter of VFD corresponds to a communication address. See "A2.5 Communication parameter" .
- 4) Write data: Request data written by the slave..
- 5) Write byte number:Request data written by the slave.=write numer*2
- 6) write data1~write data N:Request data written by the slave

2. Slave normal response message

Table A.8 Command 10H: Slave normal response message

| Slave address | Command code | Communication address | | Write data | | CRC code | |
|---------------|--------------|-----------------------|----------|------------|----------|----------|-----------|
| 1 byte | 1 byte | 2 bytes | | 2 bytes | | 2 bytes | |
| | 10H | High byte | Low byte | High byte | Low byte | Low byte | High byte |

- 1) Slave address and CRC code: See "Table A.2" .
 - 2) Command code: 10H. The same as master command
 - 3) Communication address: the same as master communication address.
 - 4) Write data: the same as master
3. Slave error response message

Table A.9 Command 10H Format of slave error response message

| Slave address | Command code | Error code | CRC code | |
|---------------|--------------|------------|----------|-----------|
| 1 byte | 1 byte | 1 byte | 2 bytes | |
| | 90H | | Low byte | High byte |

- 1)Slave address and CRC code: See "Table A.2" .
- 2)Command code: 90H. It is = 10H + 80H.

3) Error code. For detail see "A2.4 Error code" .

4. Example: To write the beginning five data of f300

Master request message: 01 10 03 00 00 05 0A 00 01 00 03 00 04 00 01 00 0B 9D AE

(Suppose f300=1; f301=3; f302=4; f303=1; f304=11)

Normal response message: 01 10 03 00 00 05 00 4E

Error response message: 01 90 03 0C 01 (Suppose current writing operation cannot be performed)

Table A.10 error code explanation

| Error code | Description |
|------------|---|
| 01 | Command code error |
| | Command code other than 03H 06 and 10H is set in the request message |
| 02 | Communication address error |
| | Visited communication address does not exist. The register corresponding to the communication address does not permit performance of the action demanded by the current command code. |
| 03 | Data setting error |
| | Written data exceeds the allowable range of the register. Improper setting of certain parameter in the request message. |
| 04 | Unable to continue implementing the master's request. |
| | Error occurs during the process of writing data. Currently the register corresponding to the communication address does not permit performance of the action demanded by the command code. |

A2.3 Cyclic redundancy check (CRC)

Modbus-RTU's communication message uses cyclic redundancy check (CRC) for transmission error check.

During each communication, the sender computes CRC code of transmitted data according to CRC rules, then sends the data by attaching the CRC code to them; After receiving the data, the receiver re-computes the CRC code according to the same rules. The computed content does not include the received CRC code. The receiver compares the re-calculated CRC code with the received code. If they are not the same, the transmitted data are determined to be false.

This VFD adopts CRC16 rule for message check of serial communication. Every CRC code consists of 2 bytes, including 16-bit binary value. The calculation is as follows:

- 1) Initialize CRC register (16 bit) to 0xFFFF;
- 2) Perform XOR to the first byte (slave address) and the low 8 bits of the register, and then put the computed result back to CRC register;
- 3) Make a right shift by 1 bit to the content of CRC register and fill in the highest bit with 0;
- 4) Check the shift-out bit after right shift;

If the shift-out bit is 0, repeat 3), namely, make another right shift;

If the shift-out bit is 1, make XOR to CRC register and 0xA001, and put the computed result back to the CRC register;

- 5) Repeat steps 3) and 4) until 8 right shifts are made. Implement the same procedure to all the 8-bit data; Repeat steps 2) ~ 5) to implement the processing of the next byte in the message;

6) After all the bytes in the message are computed according to the above procedures, the content in the CRC register is the CRC code.

7) After the CRC code is acquired through the above-mentioned method, attach it to the transmitted data and send them. It is necessary to exchange the high and low bytes of the CRC code, namely, to send the low byte firstly and then the high byte.

There are two methods to compute CRC code with software: table look-up and on-line computation. Computation speed of the table look-up is fast but its table data occupy considerable space; On-line computation method requires no table data. It saves space but needs much time. Suitable computation method is selected according to concrete circumstance during application.

A2.4 Error code

When the slave is not able to implement master's request, the slave gives feedback of corresponding error code to indicate cause of the current error. Refer to the following table for the concrete meaning of error code.

Table A. 11 Error code explanation

| Error code | Description |
|------------|---|
| 01 | Command code error |
| | <ul style="list-style-type: none"> Command code other than 03H 06 and 10H is set in the request message |
| 02 | Communication address error |
| | <ul style="list-style-type: none"> Visited communication address does not exist. The register corresponding to the communication address does not permit performance of the action demanded by the current command code. |
| 03 | Data setting error |
| | <ul style="list-style-type: none"> Written data exceeds the allowable range of the register. Improper setting of certain parameter in the request message. |
| 04 | Unable to continue implementing the master's request. |
| | <ul style="list-style-type: none"> Error occurs during the process of writing data. Currently the register corresponding to the communication address does not permit performance of the action demanded by the command code. |

A2.5 Communication parameter

1. Control parameter

Control parameters are edited through serial communication in order to realize VFD 's function setting, running frequency setting, start/stop control and logic/analog output setting.

1) Basic parameters

Basic parameters consist of 10 groups: F0 – F9. They are used to control the function setting of the VFD . Their detailed description, communication addresses and value ranges are shown in " 6.Detailed description of parameters" .

Note: The communication address of the basic parameter corresponds to its display code. However, it is required to change F at the highest bit to 0;

Example: The display code of parameter " Running command selection is f001, so the corresponding communication address is 0001;

Another example: The display code of parameter "Default keyboard panel is play value" is f702, so the corresponding communication address is 0X702.

2)Communication control word (Communication address: fa05)

Table A.12 Detailed description of communication control word

| Bit | Description of function | 0 | 1 | Default value |
|-----|---|---------------------------------------|---------------------------------------|---------------|
| 0 | JOG | NO-JOG | Jog frequency | 0 |
| 1 | Forward/reverse rotation | Forward rotation | Reverse rotation | 0 |
| 2 | Running/stop | Stop | Running | 0 |
| 3 | Free stop | No action | Free stop | 0 |
| 4 | Emergency stop | No action | Emergency stop | 0 |
| 5 | Fault reset | No action | Reset | 0 |
| 6 | Given frequency by communication | Disable | Enable | 0 |
| 7 | Given code by communication | Disable | Enable | 0 |
| 8 | Multi-speed 1 | OFF | ON | 0 |
| 9 | Multi-speed 2 | OFF | ON | 0 |
| 10 | Multi-speed 3 | OFF | ON | 0 |
| 11 | Multi-speed 4 | OFF | ON | 0 |
| 12 | Motor parameter switch | 1nd Motor Parameter | 2nd Motor Parameter | 0 |
| 13 | PID control Disabling | Enabling PID control | Disabling PID control | 0 |
| 14 | Acceleration/ deceleration curve switch | Acceleration/ deceleration curve 1 | Acceleration/ deceleration curve 2 | 0 |
| 15 | DC braking | No DC braking | DC braking start | 0 |

3)Communication running frequency setting(communication address FA08)

Table A.13 communication running frequency setting

| Bit | Description of function | Default |
|------|--|---------|
| 0-15 | Running frequency data of communication setting. Hexadecimal setting: 50Hz (50Hz)x100 = 5000→1388Hz. It is if setting: 50Hz, write 1388H in the FA08 address | 0.0 |

4)Communication analog output setting (Communication address: FA16)

Table A.14 Communication analog output setting

| Bit | Description of function | Lower limit | Upper limit | Default |
|------|--|--------------|-----------------|---------|
| 0-15 | Analog output data of communication setting (in correspondence with analog output function 15) | 0 (0000H) | 1023 (03FFH) | 0 |

2. Monitoring parameter

Monitoring parameters can be read through serial communication to see the running state of the converter. The following table is the description of monitoring parameters.

Table A.15 Monitoring parameters 1

| No. | Communication address | Description of function | Unit | Note |
|-----|-----------------------|-----------------------------------|---------|----------------------------|
| 1 | FD03 | Real-time running state | - | See table A.14 for detail |
| 2 | FD12 | Real-time running frequency | 0.01 Hz | |
| 3 | FE18 | Actual output frequency | 0.01 Hz | |
| 4 | FE09 | DC bus input voltage | 0.01 % | |
| 5 | FE10 | Output voltage | 0.01 % | |
| 6 | FE08 | Output current | 0.01 % | |
| 7 | FE20 | Output torque | 0.01 % | |
| 8 | FE29 | Output power | 0.01 kW | |
| 9 | FE50 | Motor speed (estimated) | 1r pm | |
| 10 | FE11 | Logic input | - | See Table A.15 for details |
| 11 | FE12 | Logic output | - | See Table A.16 for details |
| 12 | FE30 | Logic input AI1 (10-bit accuracy) | - | Range (0-1023) |
| 13 | FE31 | Logic input AI2 (10-bit accuracy) | - | Range (0-1023) |
| 14 | FC39 | Fault monitoring | - | See A.17 for details |
| 15 | FA35 | Given press percent | | See 6.1.11 for details |
| 16 | FA36 | Given press percent | | See 6.1.11 for details |
| 17 | FE41 | VFD rated current | 0.1A | |

Table A.16 Monitoring parameter specification 2

| No. | Communication address | Description of function | Unit | Note |
|-----|-----------------------|-----------------------------|------------------------|----------------------------|
| 1 | E000 | Real-time running state | - | See table A.14 for details |
| 2 | E001 | Real-time running frequency | 0.01Hz | |
| 3 | E002 | output current | According f534 setting | Suggest f534=1 |
| 4 | E003 | Fault monitoring | - | See Table A.17 for details |
| 5 | E004 | PID given | | |
| 6 | E005 | PID feedback | | |
| 7 | E006 | output voltage | V | |
| 8 | E007 | Motor speed (estimated) | 1rpm | |
| 9 | E008 | Output torque | 0.01% | |
| 10 | E009 | DC bus input voltage | V | |
| 11 | E010 | Input power | 0.01kW | |
| 12 | E011 | Output power | 0.01kW | |
| 13 | E012 | Input power accumulates | W.h | |

| No. | Communication address | Description of function | Unit | Note |
|-----|-----------------------|------------------------------------|-------------------------|----------------------------|
| 14 | E013 | Output power accumulation | Unit accoring f617 dada | |
| 15 | E014 | Running time accumulation | Hour | |
| 16 | E015 | Logic input | | See Table A.15 for details |
| 17 | E016 | Logic output | | See Table A.16 for details |
| 18 | E017 | Analog input AI1(10-bit precision) | | Range(0~1023) |
| 19 | E018 | Analog input AI2(10-bit precision) | | Range(0~1023) |

Table A.17 Logic input state monitoring

| Communication address | Description of function | | |
|-----------------------|---|-----|----|
| FE11/FD01/E015 | Logic input state monitoring | | |
| Bit | Description | 0 | 1 |
| 0 | Terminal LI1 | OFF | ON |
| 1 | Terminal LI2 | OFF | ON |
| 2 | Terminal LI3 | OFF | ON |
| 3 | Terminal LI4 | OFF | ON |
| 4 | Terminal LI5 | OFF | ON |
| 5 | Terminal LI6 | OFF | ON |
| 6 | Terminal LI7 or as AI1 when logic input | OFF | ON |
| 7 | Terminal LI8 or as AI2 when logic input | OFF | ON |
| 8-15 | Reserved | - | - |

Table A.18 Logic Output state monitoring

| Communication address | Description of function | | |
|-----------------------|-------------------------------|-----|----|
| FE12/FD02/E016 | Logic output state monitoring | | |
| Bit | Description | 0 | 1 |
| 0 | Terminal LO1-CLO | OFF | ON |
| 2 | Relay T1 | OFF | ON |
| 3-15 | Reserve | - | - |

Table A.19 Real-time running state monitoring

| Communication address | Description of function | | |
|-----------------------|------------------------------------|------------------|------------------|
| FD03/E000 | Real-time running state monitoring | | |
| Bit | Description | 0 | 1 |
| 0 | Reserved | - | - |
| 1 | Fault | No fault | Tripping |
| 2-8 | Reserved | - | - |
| 9 | Forward/reverse rotation | Forward rotation | Reverse rotation |
| 10 | Running/stop | Stop | Running |
| 11-15 | Reserved | - | - |

Table A.20 Fault monitoring

| Communication address | Description of function | |
|-----------------------|---------------------------------|---------------|
| FC39/E003 | Fault monitoring | |
| Value | Corresponding fault | Panel display |
| 0000H | No fault | nerr |
| 0001H | Acceleration overcurrent | e-01 |
| 0002H | Deceleration overcurrent | e-01 |
| 0003H | Constant speed overcurrent | e-01 |
| 0009H | Output phase failure | e-42 |
| 000AH | Acceleration overvoltage | e-11 |
| 000BH | Deceleration overvoltage | e-11 |
| 000CH | Constant speed overvoltage | e-11 |
| 000DH | VFD overload | e-21 |
| 000EH | Motor overload | e-22 |
| 0010H | Overheat tripping | e-24 |
| 0011H | Emergency tripping | e-43 |
| 0012H | EEPROM error 1 (write error) | e-31 |
| 0013H | EEPROM error 2 (Read error) | e-31 |
| 0014H | EEPROM error 3 (Internal error) | e-31 |
| 0018H | External communication error | e-33 |
| 001AH | Current detection fault | e-34 |
| 001EH | Undervoltage | e-12 |

Appendix B: Brake Unit/Resistance Selection

When fast or precise motor deceleration is required in transmission applications, brake units and brake resistors are used to release the energy back to the DC bus in order to obtain the desired braking torque and avoid excessive pump voltage during deceleration that will affect the safe operation of the equipment. Please choose the appropriate brake unit and brake resistance according to the VFD capacity and specific working conditions. Under general working conditions, the brake resistance can be selected according to the configuration in Table B.1.

Table B.1 Brake unit resistance selection

| VFD MODEL | Brake unit | | Brake resistor | | |
|--------------------|-------------|---------|----------------|--------|------|
| | Description | QTY | VALUE | POWER | QTY |
| RVE32-T3-0R7G/1R5P | BUILD-IN | 1 | 750 Ω | 110W | 1 |
| RVE32-T3-1R5G/2R2P | | 1 | 400 Ω | 260W | 1 |
| RVE32-T3-2R2G/3P | | 1 | 250 Ω | 320W | 1 |
| RVE32-T3-3G/4P | | 1 | 250 Ω | 320W | 1 |
| RVE32-T3-4G/5R5P | | 1 | 150 Ω | 400W | 1 |
| RVE32-T3-5R5G/7R5P | | 1 | 100 Ω | 520W | 1 |
| RVE32-T3-7R5G/11P | | 1 | 75 Ω | 1040W | 1 |
| RVE32-T3-11G/15P | | 1 | 50 Ω | 1040W | 1 |
| RVE32-T3-15G/18R5P | | 1 | 40 Ω | 1500W | 1 |
| RVE32-T3-18G/22P | | 1 | 40 Ω | 1500W | 1 |
| RVE32-T3-22G/30P | | 1 | 20 Ω | 8kW | 1 |
| RVE32-T3-30G/37P | | 1 | 20 Ω | 8kW | 1 |
| RVE32-T3-37G/45P | | 1 | 13.6 Ω | 10kW | 1 |
| RVE32-T3-45G/55P | | CBU4045 | 1 | 13.6 Ω | 10kW |
| RVE32-T3-55G/75P | CBU4055 | 1 | 12 Ω | 12kW | 1 |
| RVE32-T3-75G/90P | CBU4075 | 1 | 10 Ω | 20kW | 1 |
| RVE32-T3-90G/110P | CBU4110 | 1 | 6.8 Ω | 30kW | 1 |
| RVE32-T3-110G/132P | | 1 | 6.8 Ω | 30kW | 1 |
| RVE32-T3-132G/160P | CBU4160 | 1 | 5 Ω | 40kW | 1 |
| RVE32-T3-160G/185P | | 1 | 5 Ω | 40kW | 1 |
| RVE32-T3-185G/200P | CBU4220 | 1 | 3.2 Ω | 60kW | 1 |
| RVE32-T3-200G/220P | | 1 | 3.2 Ω | 60kW | 1 |
| RVE32-T3-220G/250P | | 1 | 3.2 Ω | 60kW | 1 |
| RVE32-T3-250G/280P | CBU4300 | 1 | 2.5 Ω | 80kW | 1 |
| RVE32-T3-280G/315P | | 1 | 2.5 Ω | 80kW | 1 |
| RVE32-T3-315G/355P | | 1 | 2.5 Ω | 80kW | 1 |

| VFD MODEL | Brake unit | | Brake resistor | | |
|---------------|-------------|-----|----------------|-------|-----|
| | Description | QTY | VALUE | POWER | QTY |
| RVE32-T3-355G | CBU4220 | 2 | 3.2 Ω | 60kW | 2 |
| RVE32-T3-400G | | 2 | 3.2 Ω | 60kW | 2 |
| RVE32-T3-500G | CBU4300 | 2 | 2.5 Ω | 80kW | 2 |
| RVE32-T3-560G | CBU4220 | 3 | 3.2 Ω | 60KW | 3 |
| RVE32-T3-630G | CBU4220 | 3 | 3.2 Ω | 60KW | 3 |
| RVE32-T3-710G | CBU4220 | 3 | 3.2 Ω | 60KW | 3 |
| RVE32-T3-800G | CBU4220 | 3 | 3.2 Ω | 60KW | 3 |

Note:

1. Please select the resistance value and power of the brake resistor according to the data provided by our company.
2. The data in the above table are designed according to 100% braking torque and 10% braking utilization rate. If the user wants to use a larger braking torque, the resistance value of the braking resistance can be appropriately reduced and its power can be enlarged.
3. For applications requiring frequent braking, the power of braking resistor shall be appropriately increased according to specific working conditions

